

dig*i*ETUI

Kamera sucht Tasche

Taschengrößen-Übersicht für Kameras



S+M REHBERG

DIGITAL+PHOTO+MORE

www.digiETUI.de



Canon Digital Ixus 1000 is	H2,T1	Casio EX-FH100	T2/H4/A4	Fuji Fine Pix T300	H2/A3/T1
Canon Digital Ixus 110 is	H0,T1	Casio EX-FS10	H0,T1	Fuji Fine Pix Z10	H1/A1/H0
Canon Digital Ixus 115/117	T1/H2/A1	Casio EX-H10	A2,T2	Fuji Fine Pix Z100 FD	H1/T1
Canon Digital Ixus 120	H0/A1/T1	Casio EX-H15	T2/H4/A4	Fuji Fine Pix Z20FD	A1/T1/H1
Canon Digital Ixus 130	T1/H1/A1	Casio EX-H20G	T2,A4	Fuji Fine Pix Z3	H1/A1/H0
Canon Digital Ixus 200	H2/T1	Casio EX-S12	H0,T1	Fuji Fine Pix Z30	A1,T1
Canon Digital Ixus 210 is	H2/T1	Casio EX-S200	H0,T1	Fuji Fine Pix Z300	T1/H0/A1
Canon Digital Ixus 220	H1/A1/T1/	Casio EX-Z 330	T1	Fuji Fine Pix Z33WP	H1,A1,T1
Canon Digital Ixus 300 is	T1/A3/H2	Casio EX-Z2000	H2	Fuji Fine Pix Z5FD	H0/T1
Canon Digital Ixus 300HS	T1	Casio EX-Z2300	T1,H2	Fuji Fine Pix Z70	T1/H0/A1
Canon Digital Ixus 800 is	H1/A3	Casio EX-Z250	H0	Fuji Fine Pix Z700	H0/T1
Canon Digital Ixus 850 is	H2/T1/A3	Casio EX-Z270	H0/A1/T1	Fuji Fine Pix Z800EXR	H0,T1
Canon Digital Ixus 860 is	T1/H2/A3	Casio EX-Z350	T1,H0	Fuji Fine Pix Z90	H1/H0
Canon Digital Ixus 900TI	H2/T1/A3	Casio EX-Z500	H1/A1	JVC GZ MC 100	H4
Canon Digital Ixus 95	H0//A1/T1	Casio EX-Z550	T1/H2	Kodak C 1013	A2
Canon Digital Ixus 950 is	T1/H2/A4	Casio EX-Z750	H1/A1	Kodak C 913	A2
Canon Digital Ixus 950 TI	H2/T1/A3	Casio EX-ZH30	T2,A4	Kodak C160	H2
Canon Digital Ixus 960 is	T1/H2/A3	Casio EX-ZR10	T1/H2	Kodak C180	A3
Canon Digital Ixus 970 is	T1/H2/A3	Casio EX-ZR100	T2/A4/H4	Kodak C713+C813	A2
Canon EOS 1000+ 18-55	S0/Colt2	Casio EX-ZS10	T1/H0	Kodak C743	A2
Canon EOS 1100+ 18-55	S0/Colt2	Casio EX-ZS5	T1/H2	Kodak C875	A2/T2
Canon EOS 400D+18-55	S0	Casio Hi-SPEED F1	S0/COLT2	Kodak M 1033	H0
Canon EOS 40D + 18-55	S1	Casio Hi-SPEED FH20,FH25	B2,COLT1	Kodak M 1063	H0
Canon EOS 450D+ 18-55	S0/Colt2	Casio Hi-Zoom EX-V8	H0/T1/A4	Kodak M 1073	H0
Canon EOS 550+18-135	COLT3	Fuji Fine Pix 3DW3	A4	Kodak M 1093IS	H0
Canon EOS 550+18-55	S0/COLT2	Fuji Fine Pix F	T2/H4	Kodak M 320	H0/T1
Canon EOS 60 D+18-135	Colt 3	Fuji Fine Pix F300EXR	A4,H4,T2	Kodak M 340	H0/T1
Canon EOS 600D+18-135	COLT3	Fuji Fine Pix F5000,5500	T2/H4/A4	Kodak M 380	H2
Canon EOS 600D+18-55	Colt2	Fuji Fine Pix F70	T2/H2/A3	Kodak M 753	T1/H0
Canon EOS 7D + 15-55	Colt3	Fuji Fine Pix F70 EXR	H2/T2	Kodak M 833	H0/A2
Canon PowerShot A1200	H2/A3	Fuji Fine Pix F700	A4	Kodak M 853	T1/H1
Canon PowerShot A3000	H2	Fuji Fine Pix F810	A4/H3	Kodak M 863	H0/A1/T1
Canon PowerShot A3100	H2	Fuji Fine Pix HS10	COLT2	Kodak M 873	H0/A1
Canon PowerShot A550	A2//H4	Fuji Fine Pix HS20	S0	Kodak M 883	H2
Canon PowerShot A580 is	A2	Fuji Fine Pix J150W	H1	Kodak M 893	H2/A3
Canon PowerShot A590 is	A2	Fuji Fine Pix J20	H0,A1	Kodak P 712	B2
Canon PowerShot A700	H4/A2	Fuji Fine Pix J250	A3,H2,T1	Kodak P 850	B2
Canon PowerShot A720	H4/A2	Fuji Fine Pix J50	H2	Kodak P 880	S0
Canon PowerShot A800	H2/A3	Fuji Fine Pix JZ500	T1/H0	Kodak V 803	H2
Canon PowerShot A2200	H2/A3/T1	Fuji Fine Pix LV100	T1/H0	Kodak Z 1012IS	B2/COLT1
Canon PowerShot A3300	H2/A3/T1	Fuji Fine Pix S1000	B1/COLT1	Kodak Z 1015IS	B1/COLT1
Canon PowerShot A2000	A3/H3/T2	Fuji Fine Pix S1500	COLT1	Kodak Z 1275	A2
Canon PowerShot A2100	A2,T2	Fuji Fine Pix S1800	Colt1	Kodak Z 650	B1/U1
Canon PowerShot A3100is	H2	Fuji Fine Pix S2 Pro	S1	Kodak Z 712is	B1
Canon PowerShot A720 is	T2/A2	Fuji Fine Pix S20 Pro	B2	Kodak Z 740	B1
Canon PowerShot G11,G12	Colt0	Fuji Fine Pix S2000HD	COLT1	Kodak Z 7590	B1
Canon Powershot G9,G10	Colt0	Fuji Fine Pix S2800HD	COLT1	Kodak Z 812 IS	B1
Canon PowerShot S5 is	B2	Fuji Fine Pix S2950	COLT1	Kodak Z 8612	B2/COLT1
Canon Powershot S90	H2/T2	Fuji Fine Pix S3 Pro	S1	Kodak Z 885	A2
Canon Powershot S95	H2,T1	Fuji Fine Pix S3500	B2	Kodak Z 915	T2
Canon PowerShot SX 200IS	H3,T2	Fuji Fine Pix S5200EXP	S0/Colt2	Kodak ZD 710 HD	B1
Canon PowerShot SX 220IS	H3,T2	Fuji Fine Pix S5500	B2	Kodak ZX1	A4
Canon PowerShot SX 230IS	H3,T2	Fuji Fine Pix S5600	S0	Leica C-Lux 1	H1
Canon PowerShot SX100 is	---	Fuji Fine Pix S5700	B2	Leica C-Lux 2	H1
Canon Powershot SX20	Colt1	Fuji Fine Pix S6500FD	B2	Leica D-Lux 2	H4
Canon PowerShot SX210is	T2/H4	Fuji Fine Pix S8100FD	B2/COLT1	Leica D-Lux 3	T2
Canon PowerShot SX30 is	COLT 1 B2/	Fuji Fine Pix S9500	S0	Leica Digilux 3	S1
Canon SX110IS	H4/T2	Fuji Fine Pix S9600	S1	Leica V-Lux 1	B2
Casio EX-FC100	H2	Fuji Fine Pix T200	T1	Leica X1	Colt0

Nikon Coolpix L100	B1, COLT1	Olympus E620 mit 14-42	S0/Colt2	Panasonic DMC-FX10	H1/A1/T1
Nikon Coolpix L110	B1, COLT1	Olympus FE 4030	H0/H1/A1	Panasonic DMC-FX100	H2/T1
Nikon Coolpix L120	Colt1	Olympus FE 5010	H2	Panasonic DMC-FX12	H1/A1/T1
Nikon Coolpix L19	H2	Olympus FE 5020	A1/H1/T1	Panasonic DMC-FX150	H2/T1/A3
Nikon Coolpix L20	H2/A3	Olympus FE 5035	H0,T1	Panasonic DMC-FX30	H0/A3/T1
Nikon Coolpix L21	T1/H2/A3	Olympus FE 5050	H0,T1	Panasonic DMC-FX33	H1/H0/T1
Nikon Coolpix L22	H2/A3	Olympus Mju 1010	H2	Panasonic DMC-FX35	H0/A1
Nikon Coolpix P100	/B2	Olympus Mju 1020	H2	Panasonic DMC-FX37	H2/T1/A3
Nikon Coolpix P300	T2/A4	Olympus Mju 1030 SW	H0	Panasonic DMC-FX40	H1,T1
Nikon Coolpix P500	Colt1	Olympus Mju 1040	H0/H1/T1	Panasonic DMC-FX50	H2/A1T1
Nikon Coolpix P5000	H4/A2/T2	Olympus Mju 1050 SW	H2/A3	Panasonic DMC-FX500	H2/A3
Nikon Coolpix P5100	T2/A2	Olympus Mju 1060	H2	Panasonic DMC-FX550	H2,T1
Nikon Coolpix P7000	-----	Olympus Mju 1200	H2/T1/A3	Panasonic DMC-FX60	A1/H0
Nikon Coolpix P90	B2/Colt1	Olympus Mju 3000	T2/H2	Panasonic DMC-FX66	T1/H2
Nikon Coolpix S1000PG	T2/H2	Olympus Mju 6010	A3/H2	Panasonic DMC-FX700	H2/t1
Nikon Coolpix S1000PJ	T2	Olympus Mju 6020	T2/H2	Panasonic DMC-FX700	H2,T1
Nikon Coolpix S1100PI	T2	Olympus Mju 7000	H2,T2	Panasonic DMC-FX77	T1/H0
Nikon Coolpix S220	H1,T1	Olympus Mju 7000	H2/T2	Panasonic DMC-FZ 100	Colt2
Nikon Coolpix S230	A1,H1,T1	Olympus Mju 7010	H2/T1/A3	Panasonic DMC-FZ30	S0
Nikon Coolpix S3000	H0/T1	Olympus Mju 7040	T2/H2	Panasonic DMC-FZ38	B2/Colt1
Nikon Coolpix S3100	H0/T1	Olympus Mju 720sw	H1/H0/T1	Panasonic DMC-FZ45	Colt 2
Nikon Coolpix S4000	T1/H1/H0	Olympus Mju 725 sw	H1/H0/T1	Panasonic DMC-FZ50	S0/COLT2
Nikon Coolpix S4100	H0/T1	Olympus Mju 730	H2/H0	Panasonic DMC-FZ8	B2
Nikon Coolpix S510	A3/T1/H2	Olympus Mju 770SW	A1/H0/T1	Panasonic DMC-G1K	COLT2
Nikon Coolpix S5100	H2/T1	Olympus Mju 790 SW	H0	Panasonic DMC-G2 14-42	Colt2
Nikon Coolpix S520	H0	Olympus Mju 8010	T2/H2	Panasonic DMC-GF-1 14-55	B2/Colt1
Nikon Coolpix S52C	H0	Olympus Mju 840	H0	Panasonic DMC-GF-1 1,7/20	Colt0
Nikon Coolpix S560	A1,H2,T1	Olympus Mju 9000	H2,T2	Panasonic DMC-GF2 14-42	B2/Colt1
Nikon Coolpix S570	A1,H1,T1	Olympus Mju 9000	H2/T2	Panasonic DMC-GH2 14-140	Colt2
Nikon Coolpix S610	H2	Olympus Mju 9010	T2/H2	Panasonic DMC-L10 14-50	S1
Nikon Coolpix S6100	H2/T1	Olympus Pen E-P1 14-42	B2	Panasonic DMC-LX5	B1/Colt0
Nikon Coolpix S610C	H2	Olympus Pen E-P1 17mm	Colt0	Panasonic DMC-S1,S3	H1/A3/T1
Nikon Coolpix S620	H1,T1	Olympus Pen EPL1 14-42	B2/Colt1	Panasonic DMC-TZ18/TZ22	H4/A4/ T2/
Nikon Coolpix S630	HE	Olympus SP 510 UZ	B2	Panasonic DMC-TZ2,TZ3	A4/H3/T2
Nikon Coolpix S640	A1,H1,T1	Olympus SP 560	B1/U1	Panasonic DMC-TZ4 TZ5	H3/T27A4
Nikon Coolpix S700	A3/T1/H2	Olympus SP 565 UZ	COLT1	Panasonic DMC-TZ6,TZ6	H3/T27A4
Nikon Coolpix S710	H2	Olympus SP 570 UZ	COLT1/B2	Panasonic DMC-TZ8,TZ10	H4, A4, T2
Nikon Coolpix S7C	H0	Olympus SP 590UZ	COLT1	Panasonic DMC-ZX-1 ZX-3	A3/H2
Nikon Coolpix S8000	T2/A4	Olympus SP600	COLT1	Pentax ist D 18-55	S0
Nikon Coolpix S8100	T2/A4	Olympus SP610	Colt1	Pentax ist DL18-55	S0
Nikon Coolpix S9100	T2/A4	Olympus SP800	COLT1	Pentax ist DS 2 18-55	S0
Nikon D200 18-55	S1	Olympus SZ20	T2/A4	Pentax K-7 mit 18-55	Colt2/S0
Nikon D300 S 18-105	S1	Olympus TG310	T1	Pentax K-X mit 18-55	S0/COLT2
Nikon D3000 18-55	S0/Colt2	Olympus TG610	T2/H2	Pentax K10 d 18-55	S0
Nikon D3100 18-55	S0/Colt2	Olympus VG130	T1	Pentax K110 d 18-55	S0
Nikon D50 18-55	S1	Olympus XZ1	Colt0	Pentax K200D	S1
Nikon D5000 18-55	S0/Colt2	Panasonic DMC-F62	H2/T1	Pentax K20D	S1
Nikon D60 18-55	S0/Colt2	Panasonic DMC-FP7,FP5	H0/T1	Pentax K5 18-55	S0,COLT2
Nikon D60 18-55	S1	Panasonic DMC-FP8	A1/H0	Pentax KM mit 18-55	COLT2/S0
Nikon D80 118-55	S1	Panasonic DMC-FS10	H0/T1	Pentax KR 18-55	S0, COLT2
Nikon D90 18-105	Colt3	Panasonic DMC-FS11	H0/T1	Pentax Optio E90	H2/T1
Nikon D90 18-55	S0/	Panasonic DMC-FS16,FS18	A1/T1	Pentax Optio H90	H2
Olympus E PL-2 14-42	B2/COLT1	Panasonic DMC-FS25	H0,A1	Pentax Optio I10	T2/H4/A4
Olympus E30 12-60	Colt3	Panasonic DMC-FS30	H2,T1	Pentax Optio M40	H0/T1
Olympus E330 14-45	S1	Panasonic DMC-FS33	H2	Pentax Optio M90	H2,A3,T1
Olympus E410 mit 14-42	S0	Panasonic DMC-FS35,FS37	H2/T1	Pentax Optio P70	H0/T1/A1
Olympus E450 mit 14-42	S0/Colt2	Panasonic DMC-FS62	T1/H2	Pentax Optio P80	H0,A1,T2
Olympus E500 mit 14-42	S0	Panasonic DMC-FS7	H0/T1	Pentax Optio RS1000	A3,T1,H2
Olympus E510 mit 14-42	S0	Panasonic DMC-FT-1	H2	Pentax Optio RZ10	A2,H3,T2
Olympus E520 mit 14-42	S0	Panasonic DMC-FT10	T2	Pentax Optio S1	T1/H1/A1

Pentax Optio S60	H2/A3	Samsung GX10 10-17	S1	Sony DSC-H55	T1/H1/A1
Pentax Optio S7	H1	Samsung M20,M10	H3	Sony DSC-H70	T2/H3
Pentax Optio SVi	H2/A3	Samsung NX10 20-50	COLT1,B2	Sony DSC-H9	B2/U1
Pentax Optio V10	H0/H1	Samsung NX10 mit 18-55	COLT2/S0	Sony DSC-HX1	COLT1
Pentax Optio W60	H2/A4	Samsung NX10 mit 30mm	COLT1	Sony DSC-HX5VN	T2/A4/H2
Pentax Optio W80	H2/A4	Samsung NX100 20-50	COLT1,B2	Sony DSC-HX7V	T2/H4
Pentax Optio W90	H2/A4	Samsung NX11 mit18-55	S0	Sony DSC-S210	H2
Pentax Optio WS80	T1/H1/A1	Samsung PL 170	H2T1/H3	Sony DSC-S2100	H2
Pentax Optio X70	B2, COLT1	Samsung PL120	T1/H1	Sony DSC-T110	T1/H0
Pentax Optio x90	Colt1	Samsung PL20	T1/H2	Sony DSC-T70	H0/A1
Pentax Optio Z10	A3/H2/T1	Samsung PL210	A4/T2	Sony DSC-T700	A1/H0/T1
Ricoh,CX1 - CX5	H4/A4/T2	Samsung ST 45	H0/T1	Sony DSC-T77	H0
Ricoh CXR mit A12	B2	Samsung ST100	T1/H1/A3	Sony DSC-T9	A1/H0
Ricoh CXR mit S10	B2	Samsung ST1000	H0/A3,T1	Sony DSC-T90	H0/T1
Ricoh GR digital	H3/A4	Samsung ST30	H1/A1	Sony DSC-T900	H0
Ricoh GR digital+Zubehör	B1	Samsung ST500	H2	Sony DSC-TX1	A1/H0
Ricoh GX200 +DW6	B2	Samsung ST5000	T2/H2/A4	Sony DSC-TX10	T1/H0
Ricoh R8, R10	T2/A4/H4	Samsung ST550	H2	Sony DSC-TX100V	H0/T1
Samsung Digimax ES65	T1/H2	Samsung ST60	T1/H1/A1	Sony DSC-TX5	H0/T1
Samsung Digimax ES75	H2/T1	Samsung ST65	T1/H2	Sony DSC-TX7L	H0
Samsung Digimax FL820	H2	Samsung ST90	T1/H2	Sony DSC-TX9	H0
Samsung Digimax HZ10W	H4/H3/A2/T2	Samsung ST90	T1/A3/H1	Sony DSC-TX99	H0
Samsung Digimax HZ15W	H4/A2/T2	Samsung ST95	H2	Sony DSC-W150	H1/A1/T1
Samsung Digimax L83T	H0/A2	Samsung WB1000	H2,A4,T2	Sony DSC-W180	H0/T1
Samsung Digimax LZ4	H0	Samsung WB2000/200	T2/A4/H2	Sony DSC-W230	H2,T1
Samsung Digimax NV 24 HD	H2/A3	Samsung WB210	T2	Sony DSC-W270	A3/H2
Samsung Digimax NV10	H0	Samsung WB500	T2	Sony DSC-W290	H2/A3
Samsung Digimax NV100HD	H2/A3	Samsung WB550	T2/H4/A4	Sony DSC-W30	H2/A3/T1
Samsung Digimax NV11	H2	Samsung WB600	T2/H4/A4	Sony DSC-W300	H2/T1
Samsung Digimax NV15	H2/A3	Samsung WB650	T2/A4/H3	Sony DSC-W310	T1/A1
Samsung Digimax NV20	H2/A3	Samsung WB700	S1	Sony DSC-W320	T1/H1/A1
Samsung Digimax NV3	H0	Sigma SD 10 mit 18-200	S1	Sony DSC-W330	H0,T1
Samsung Digimax NV30	H2/T1	Sigma SD 14 mit 18-200	S1	Sony DSC-W350	T1/H1/A1
Samsung Digimax NV8	H2/A4	Sigma SD 15 mit 18-200	Colt3	Sony DSC-W360	T1/H1/A1
Samsung Digimax NV9	H2/A1	Sony a 230 mit 16-105	S0/Colt2	Sony DSC-W380	H1/A3/T1
Samsung Digimax PL10	H0/A1	Sony a 230 mit 18-70	S0/COLT2	Sony DSC-W390	H0,T1
Samsung Digimax PL100	T1/H2	Sony a 290 mit 18-55	S0/Colt2	Sony DSC-W50,	H2/A3/T1
Samsung Digimax PL150	H2/A3	Sony a 300 mit 18-70	S0/COLT2	Sony DSC-W510	H1,A1
Samsung Digimax PL200	A4,H2,T2	Sony a 33 mit 18-55	S0/Colt2	Sony DSC-W530	H1/A1
Samsung Digimax PL50	T1/H2	Sony a 350 mit 18-70	Colt3	Sony DSC-W560	H0/T1
Samsung Digimax PL51	H2/T1	Sony a 380 mit 28-75 Sam	S0/COLT2	Sony DSC-W570	H1/T1
Samsung Digimax PL55	H2	Sony a 390 mit 18-55	S0	Sony DSC-W70	H2/A3/T1
Samsung Digimax PL65	H2	Sony a 450 mit 50 Sam	Colt2/S0	Sony DSC-WX1	H2/T1
Samsung Digimax PL70	H2	Sony a 500 mit 18-55	S0/COLT2	Sony DSC-WX10	T1/H2
Samsung Digimax PL80	H2	Sony a 55 mit 18-55	Colt2/S0	Sony DSC-WX9	T1/H2
Samsung Digimax PL90	H0	Sony a 550 mit 18-70	COLT2	Sony Nex 3 18-55	Colt1
Samsung Digimax S1000	H2	Sony a 560 mit 18-55	COLT2	Sony Nex 5 18-55 + Flash	Colt1
Samsung Digimax S1050	A2/H4	Sony a 580 mit 18-55	S1		
Samsung Digimax S750	H4/T2	Sony a 700 mit 1,4/85	T2		
Samsung Digimax SL202	H1/A1/T1	Sony DSC-G1	B		
Samsung Digimax SL420	A3/H2	Sony DSC-H10	B2/U1		
Samsung Digimax St100	H2	Sony DSC-H2	Colt0		
Samsung Digimax ST80	H1	Sony DSC-H20	T2		
Samsung Digimax TL100	H0/T1	Sony DSC-H3	B2/U1		
Samsung Digimax WB2000	A4	Sony DSC-H5	COLT1		
Samsung DigimaxST600	H2/T2	Sony DSC-H50			
Samsung ES65	T1/H2				
Samsung ES70	T1/H2				
Samsung EX1	Colt0				



DIGITAL+PHOTO+MORE

www.digiETUI.de

info@digiETUI.de