

18.09.2018

Art.Nr.	Marke	Produkt
3219	Acer	Allegro M310
2902	Acer	BeTouch E140
947	Acer	D100
2573	Acer	DX900
2589	Acer	E100 / E101
2801	Acer	E110
2725	Acer	E120
2793	Acer	E130
2893	Acer	E210
1344	Acer	e305
1345	Acer	e310
2704	Acer	E400
2377	Acer	F900
3012	Acer	Liquid E / Ferrari Edition
3607	Acer	Liquid E1
3554	Acer	Liquid E1 Duo Smartphone
3608	Acer	Liquid E2
3847	Acer	Liquid E3
3258	Acer	Liquid Express E320
3947	Acer	Liquid Jade
4126	Acer	Liquid Jade Z
2959	Acer	Liquid metal S120 (nur/only Plus)
2882	Acer	Liquid Mini E310
3799	Acer	Liquid S1
2675	Acer	Liquid S100
3673	Acer	Liquid Z3
3931	Acer	Liquid Z5
308	Acer	N20
309	Acer	N30
2574	Acer	n300
310	Acer	N35
2794	Acer	P300
1346	Acer	p610
1347	Acer	p630
1348	Acer	p660
3606	Acer	S500 Cloudmobile
2903	Acer	Stream S110
3995	Acer	Z 200-†
4004	Acer	Z 500
2207	AgfaPhoto	Optima 2338mT
4529	Alcatel	IDOL 4 Pro
4530	Alcatel	IDOL 4 Pro - CASEFIT
4532	Alcatel	IDOL 4S
4533	Alcatel	IDOL 4S - CASEFIT
3609	Alcatel	One Touch 6010D
3531	Alcatel	One Touch 903D

3499	Alcatel	one touch 992 D
3373	Alcatel	One Touch 997/997D/998
3758	Alcatel	One Touch Fire
4158	Alcatel	One Touch Go Play
4252	Alcatel	One Touch Idol 4
3532	Alcatel	One Touch Idol 6030D
3530	Alcatel	One Touch Idol Ultra 6033
3497	Alcatel	One Touch M Pop 5020D
4031	Alcatel	One Touch POP 2 5042d
4251	Alcatel	One Touch Pop 4
3733	Alcatel	OneTouch 4010D T POP
237	Alcatel	OneTouch 735i
238	Alcatel	OneTouch 756
4057	Alcatel	OneTouch Idol 3 (4,7")
4058	Alcatel	OneTouch Idol 3 (5,5")
3692	Alcatel	OT 4030D S Pop
3783	Alcatel	OT 4033 Pop C3
3780	Alcatel	OT 5036 Pop C5
3781	Alcatel	OT 6040 Idol X
3782	Alcatel	OT 7041 Pop C7
3734	Alcatel	OT 8000D Scribe Easy
3779	Alcatel	OT 8020 Hero
3958	Alcatel	OT Idol 2
3991	Alcatel	OT Idol 2s
3976	Alcatel	OT Idol Alpha
3736	Alcatel	OT Idol Mini 6012D
3989	Alcatel	OT Idol X+
3573	Alcatel	OT Star 6010D
3738	Alcatel	OT Tribe 3040
3732	Alcatel	OT X Pop 5035D
2881	Alcatel	OT-303
2521	Alcatel	OT-708
2877	Alcatel	OT-799
3213	Alcatel	OT-818 / 818D
3263	Alcatel	OT-918 d
2799	Alcatel	OT-980
3060	Alcatel	OT-990
3281	Alcatel	OT-991 / 991D
3266	Alcatel	OT-995
4580	Alcatel	Pop 4-6 (7070X)
4581	Alcatel	Pop 4-6 (7070X) - CASEFIT
4528	Alcatel	POP 4S
3374	Alcatel	V860
1349	Alpine	Blackbird
3943	Amazon	Fire Phone
1644	Apple	iPhone
1864	Apple	iPhone 3G

2175	Apple	iPhone 3G S
2525	Apple	iPhone 4 / 4S
3290	Apple	iPhone 5/5s/5c/SE
3615	Apple	iPhone 5c
3854	Apple	iPhone 6/6s
3855	Apple	iPhone 6/6s Plus
4087	Apple	iPhone 6s 4 Way
4088	Apple	iPhone 6s Plus 4way
4433	Apple	iPhone 7/8 - CASEFIT
4434	Apple	iPhone 7/8 Plus - CASEFIT
4231	Apple	iPhone 8/7
4232	Apple	iPhone 8/7 Plus
4595	Apple	iPhone 8/7/6S/6 Plus
4596	Apple	iPhone 8/7/6S/6 Plus - CASEFIT
4535	Apple	iPhone X
4536	Apple	iPhone X - CASEFIT
254	Apple	iPod
1654	Apple	iPod classic
252	Apple	iPod Mini - Komplettmantel
253	Apple	iPod Mini - nur Display
1196	Apple	iPod nano
1667	Apple	iPod nano 3. Generation 2 Zoll
952	Apple	iPod nano 4G
2361	Apple	iPod nano 5G 8/16GB
2691	Apple	iPod nano 6G
3485	Apple	iPod Nano 7 G, Fullbody Premium
3388	Apple	iPod Nano 7G
1674	Apple	iPod Touch
2692	Apple	iPod Touch 4G
3486	Apple	iPod Touch 5G, Fullbody Plus
3387	Apple	iPod Touch 5G/6G
1021	Apple	iPod Video/ ab 20GB
2972	Apple	Magic Trackpad
3755	Apple	Thunderbolt 27"
4068	Apple	Watch (38mm)
4069	Apple	Watch (42mm)
3280	Archos	101 G9
2606	Archos	2 Vision
2827	Archos	4.3 internet le
3862	Archos	40 Titanium
3756	Archos	45 Platinum
4075	Archos	45c Platinum
3843	Archos	50 Neon
3610	Archos	50 Platinum
3955	Archos	50b Oxygen
3956	Archos	50c Oxygen
3711	Archos	53 Platinum

3582	Archos	80 Titanium
3558	Archos	97 Xenon
3015	Asus	EeeTop PC 1610PT
312	Asus	MyPal A600
313	Asus	MyPal A620
314	Asus	MyPal A620 BT
2007	Asus	MyPal A626
2003	Asus	MyPal A696
315	Asus	MyPal A713
316	Asus	MyPal A730W
3105	Asus	N53J
3684	Asus	Nexus 7 2013
3484	Asus	Nexus 7 2012
2009	Asus	P525
2152	Asus	P552w
1702	Asus	P750
4127	Asus	T100
1350	AV Map	geosat 5
4703	AVM	FRITZ!Fon C5
3965	Avus	A 57
2924	Becker	Professional 43 control
3593	Becker	REVO.1
1692	Becker	Traffic Assist 7827
1579	Becker	Traffic Assist 7927
1578	Becker	Traffic Assist 7928
1826	Becker	Traffic Assist 7977
1351	Becker	Traffic Assist Ferrari 7929
1141	Becker	Traffic Assist Highspeed 7934 / 7988
1478	Becker	Traffic Assist PRO 7916
2036	Becker	Traffic Assist Z 099
2155	Becker	Traffic Assist Z 103
1827	Becker	Traffic Assist Z 200
2055	Becker	Traffic Assist Z 201
2167	Becker	Traffic Assist Z100
2684	Becker	Traffic Assist Z215/217
1083	BenQ-Siemens	C81
975	BenQ-Siemens	CF75
1181	BenQ-Siemens	E71
976	BenQ-Siemens	EF81
993	BenQ-Siemens	EL71
1084	BenQ-Siemens	M81
915	BenQ-Siemens	S68
960	BenQ-Siemens	S88
239	BlackBerry	7100t
240	BlackBerry	7100v
1481	BlackBerry	7230v
346	BlackBerry	

7290

241	BlackBerry		7730
1185	BlackBerry		8100
1029	BlackBerry	8700v	
1482	BlackBerry	8707v	
1335	BlackBerry		8800
2609	BlackBerry	8800/8820/8830	
3915	BlackBerry		9720
1869	BlackBerry	Bold 9000	
2345	BlackBerry	Bold 9700	
3264	BlackBerry	Bold 9790	
2985	BlackBerry	Bold 9900	
4007	BlackBerry	Classic	
1511	BlackBerry	Curve 8310	
2304	BlackBerry	Curve 8520	
2041	BlackBerry	Curve 8900	
2681	BlackBerry	Curve 9300 3G	
3378	BlackBerry	Curve 9320	
3083	BlackBerry	Curve 9360 (nur/only Plus)	
3144	BlackBerry	Curve 9380 (nur/only Plus)	
4318	BlackBerry	DTEK50	
4319	BlackBerry	DTEK60	
4333	BlackBerry	KEYone	
4134	BlackBerry	Leap	
4639	BlackBerry	Motion	
4640	BlackBerry	Motion - CASEFIT	
3939	BlackBerry	Passport	
2683	BlackBerry	Pearl 3G 9105	
2019	BlackBerry	Pearl 8110	
2465	BlackBerry	Pearl 8220	
3042	BlackBerry	PlayBook	
4151	BlackBerry	Priv	
3568	BlackBerry	Q 5	
3535	BlackBerry	Q10	
2008	BlackBerry	Storm 9500	
2344	BlackBerry	Storm2 9520	
2690	BlackBerry	Torch 9800 / 9810	
3062	BlackBerry	Torch 9860 (nur/only Plus)	
3404	BlackBerry	Z 10	
4016	BlackBerry	Z 3	
3652	BlackBerry	Z30	
4683	Blackmagic	Video Assist 5"	
3728	Blaupunkt	Endeavour 1010 10,1Zoll	
255	Blaupunkt	RX 52	
1751	Blaupunkt	Travelpilot 100	
1750	Blaupunkt	Travelpilot 200	
1749	Blaupunkt	Travelpilot 300	
3417	Blaupunkt	TravelPilot 40	

2034	Blaupunkt	Travelpilot 500
4352	Blaupunkt	TravelPilot 73
1165	Blaupunkt	TravelPilot Lucca 3.3/3.4/MP3
1801	Blaupunkt	TravelPilot Lucca 3.5
1802	Blaupunkt	TravelPilot Lucca 3.5 Edition
1352	Blaupunkt	TravelPilot Lucca 5.2
1624	Blaupunkt	TravelPilot Lucca 5.3
4747	Bosch	Intuvia
4099	Bosch	Nyon
3937	BQ	Aquaris E4.5
3963	BQ	Aquaris E5
3964	BQ	Aquaris E6
4725	BQ	Aquaris X5 PLUS-†
4726	BQ	Aquaris X5 PLUS - CASEFIT
1353	Camos	CN 770
2064	Canon	Digital IXUS 100 IS
2615	Canon	Digital IXUS 1000 HS
2402	Canon	Digital IXUS 105 IS
2063	Canon	Digital IXUS 110 IS
2991	Canon	Digital IXUS 1100 HS
2824	Canon	Digital IXUS 115 / 117 HS
2277	Canon	Digital IXUS 120 IS
3135	Canon	Digital IXUS 125 HS / 127 HS
2403	Canon	Digital IXUS 130 IS
2278	Canon	Digital IXUS 200 IS
2409	Canon	Digital IXUS 210 IS
2823	Canon	Digital IXUS 220 HS
2992	Canon	Digital IXUS 230 HS
3295	Canon	Digital Ixus 240HS
418	Canon	Digital IXUS 30
2511	Canon	Digital IXUS 300 HS
2868	Canon	Digital IXUS 310 HS
419	Canon	Digital IXUS 40
423	Canon	Digital IXUS 400
420	Canon	Digital IXUS 430
421	Canon	Digital IXUS 50
424	Canon	Digital IXUS 500
3136	Canon	Digital IXUS 500 HS
3171	Canon	Digital IXUS 510 HS
422	Canon	Digital IXUS 55
893	Canon	Digital IXUS 60
892	Canon	Digital IXUS 65
1265	Canon	Digital IXUS 70
425	Canon	Digital IXUS 700
1264	Canon	Digital IXUS 75
426	Canon	Digital IXUS 750
1725	Canon	Digital IXUS 80 IS

789	Canon	Digital IXUS 800 IS
1611	Canon	Digital IXUS 85 IS
1040	Canon	Digital IXUS 850 IS
1513	Canon	Digital IXUS 860 IS
1982	Canon	Digital IXUS 870 IS
1805	Canon	Digital IXUS 90 IS
1041	Canon	Digital IXUS 900 Ti
2065	Canon	Digital IXUS 95 IS
1461	Canon	Digital IXUS 950 IS
1514	Canon	Digital IXUS 960 IS
1797	Canon	Digital IXUS 970 IS
1989	Canon	Digital IXUS 980 IS
2071	Canon	Digital IXUS 990 IS
430	Canon	Digital IXUS i
815	Canon	Digital IXUS i Zoom
427	Canon	Digital IXUS i5
1042	Canon	Digital IXUS i7 zoom
428	Canon	Digital IXUS II
894	Canon	Digital IXUS Wireless
2616	Canon	EOS 60D / 600D
1865	Canon	EOS 1000D
3502	Canon	EOS 100D
431	Canon	EOS 10D
2830	Canon	EOS 1100
3784	Canon	EOS 1200D / 1300D
4193	Canon	EOS 1300D
433	Canon	EOS 1D
432	Canon	EOS 1D Mark II
1271	Canon	EOS 1D Mark III
2379	Canon	EOS 1D Mark IV
429	Canon	EOS 1D Mark II N
3168	Canon	EOS 1D X
4191	Canon	EOS 1D X II
434	Canon	EOS 1Ds
435	Canon	EOS 1Ds Mark II
1516	Canon	EOS 1Ds Mark III
4540	Canon	EOS 200D
437	Canon	EOS 20D
816	Canon	EOS 20Da
438	Canon	EOS 300D
439	Canon	EOS 300V
931	Canon	EOS 30D
417	Canon	EOS 350D
1039	Canon	EOS 400D
1515	Canon	EOS 40D
1728	Canon	EOS 450D / 500D
1889	Canon	EOS 50D

2401	Canon	EOS 550D
436	Canon	EOS 5D
1961	Canon	EOS 5D Mark II
3169	Canon	EOS 5D Mark III / IV
4038	Canon	EOS 5DS / 5DS R
3268	Canon	EOS 650D / 700D
3315	Canon	EOS 6D
4541	Canon	EOS 6D Mark II
3622	Canon	EOS 70D / 77D
4037	Canon	EOS 750D / 760D
2283	Canon	EOS 7D
3905	Canon	EOS 7D Mark II
4194	Canon	EOS 80D
441	Canon	EOS D30
3314	Canon	EOS M
4166	Canon	EOS M10
4039	Canon	EOS M3
4279	Canon	EOS M5 / M6
1893	Canon	FS10
1890	Canon	FS11
1892	Canon	HF10
1897	Canon	HF100
1891	Canon	HF11
2191	Canon	HF200 Legria
2552	Canon	HFS21 Legria
1894	Canon	HG20
1896	Canon	HG21
1895	Canon	HV30
3522	Canon	Ixus 132/135
3442	Canon	Ixus 140
3806	Canon	Ixus 145/150
3805	Canon	IXUS 155/180
4014	Canon	Ixus 160/175
4073	Canon	Ixus 170
4356	Canon	IXUS 185
4357	Canon	IXUS 190
3415	Canon	Ixus 255 HS
3798	Canon	Ixus 265 HS
4147	Canon	IXUS 275/285HS
289	Canon	MV30i
2279	Canon	PowerShot 120 IS
2942	Canon	PowerShot 220H
1888	Canon	Powershot A1000 IS
2067	Canon	PowerShot A1100 IS
2741	Canon	PowerShot A1200
1885	Canon	PowerShot A2000 IS
2070	Canon	PowerShot A2100 IS

2742	Canon	PowerShot A2200
3165	Canon	PowerShot A2300 / A2400 IS
2404	Canon	PowerShot A3000 IS
2405	Canon	PowerShot A3100 IS
3096	Canon	PowerShot A3200 IS
2743	Canon	PowerShot A3300 IS
3166	Canon	PowerShot A3400 IS / A4000 IS
442	Canon	PowerShot A400
443	Canon	PowerShot A410
900	Canon	PowerShot A420
895	Canon	PowerShot A430
1267	Canon	PowerShot A450
1268	Canon	PowerShot A460
1726	Canon	PowerShot A470
2107	Canon	PowerShot A480
2406	Canon	PowerShot A490
2407	Canon	PowerShot A495
444	Canon	PowerShot A510
445	Canon	PowerShot A520
896	Canon	PowerShot A530
897	Canon	PowerShot A540
1215	Canon	PowerShot A550
1270	Canon	PowerShot A560
1269	Canon	PowerShot A570 IS
1727	Canon	PowerShot A590 IS / A580 IS
448	Canon	PowerShot A60/A70
446	Canon	PowerShot A610
447	Canon	PowerShot A620
1046	Canon	PowerShot A630
1045	Canon	PowerShot A640
1517	Canon	PowerShot A650 IS
899	Canon	PowerShot A700
1044	Canon	PowerShot A710 IS
1518	Canon	PowerShot A720 IS
449	Canon	PowerShot A75
2740	Canon	PowerShot A800
450	Canon	PowerShot A85
451	Canon	PowerShot A95
2108	Canon	PowerShot D10
3167	Canon	PowerShot D20
3802	Canon	PowerShot D30
1886	Canon	PowerShot E1
3212	Canon	PowerShot ELPH 110 HS
1999	Canon	PowerShot G10
2282	Canon	PowerShot G11
2612	Canon	PowerShot G12
3344	Canon	PowerShot G15

3634	Canon	PowerShot G16
3134	Canon	PowerShot G1X
3804	Canon	PowerShot G1X Mark II
452	Canon	PowerShot G2
453	Canon	PowerShot G3
4113	Canon	PowerShot G3X
454	Canon	PowerShot G5
4142	Canon	PowerShot G5X / G9X / G9X II
455	Canon	PowerShot G6
1043	Canon	PowerShot G7
3906	Canon	PowerShot G7 X / G7 X Mark II
1519	Canon	PowerShot G9
3438	Canon	PowerShot N
3668	Canon	PowerShot N-†
3803	Canon	Powershot N100
456	Canon	PowerShot Pro 1
457	Canon	PowerShot S1 IS
3095	Canon	PowerShot S100
3313	Canon	PowerShot S110
3677	Canon	PowerShot S120
458	Canon	PowerShot S2 IS
4015	Canon	PowerShot S200
954	Canon	PowerShot S3 IS
1520	Canon	PowerShot S5 IS
459	Canon	PowerShot S50
460	Canon	PowerShot S60
461	Canon	PowerShot S70
462	Canon	PowerShot S80
2281	Canon	PowerShot S90
2614	Canon	PowerShot S95
898	Canon	PowerShot SD30
3636	Canon	PowerShot SX 170 IS
3508	Canon	PowerShot SX 270 / 280 HS
3312	Canon	PowerShot SX 50 HS
3635	Canon	PowerShot SX 510 HS
2037	Canon	PowerShot SX1 IS
2068	Canon	PowerShot SX10 IS
1521	Canon	PowerShot SX100 IS
1887	Canon	PowerShot SX110 IS
2346	Canon	PowerShot SX120 IS
2613	Canon	PowerShot SX130 IS
2993	Canon	PowerShot SX150 IS
2280	Canon	PowerShot SX20 IS
2066	Canon	PowerShot SX200 IS
2408	Canon	PowerShot SX210 IS
2829	Canon	PowerShot SX220 / SX230 HS
3172	Canon	PowerShot SX240 HS / SX260 HS

2611	Canon	PowerShot SX30 IS
3228	Canon	PowerShot SX40 HS
4036	Canon	PowerShot SX410/SX420 IS-†
3514	Canon	PowerShot SX500 IS
3930	Canon	PowerShot SX520/540 HS
3929	Canon	PowerShot SX60 HS
4153	Canon	PowerShot SX610HS
4329	Canon	PowerShot SX620 HS / SX720 HS
4479	Canon	PowerShot SX730 HS
1266	Canon	PowerShot TX1
3796	Canon	SX600/SX700/SX710 HS
258	Casio	DT-810M50E
319	Casio	E105G
317	Casio	E10G
320	Casio	E115G
321	Casio	E125G
318	Casio	E15G
322	Casio	E200G
323	Casio	EM 500G
1745	Casio	EX-F1
2081	Casio	EX-FC100
2400	Casio	EX-FH100
2643	Casio	EX-FH20
2621	Casio	EX-FH25
2119	Casio	EX-FS10
2210	Casio	EX-H10
2581	Casio	EX-H15
2735	Casio	EX-H20G
2831	Casio	EX-H30
474	Casio	EX-P505
463	Casio	EX-P600
464	Casio	EX-P700
1720	Casio	EX-S10 / Z200
465	Casio	EX-S100
2080	Casio	EX-S12
478	Casio	EX-S20
2619	Casio	EX-S200
466	Casio	EX-S500/600
1063	Casio	EX-S770
1507	Casio	EX-S880
2745	Casio	EX-TR100 TRYX
1219	Casio	EX-V7
1524	Casio	EX-V8 Hi-Zoom
2121	Casio	EX-Z1
814	Casio	EX-Z10
1739	Casio	EX-Z100
1003	Casio	EX-Z1000

1220	Casio	EX-Z1050
1522	Casio	EX-Z1080
264	Casio	EX-Z11
475	Casio	EX-Z110
476	Casio	EX-Z120
1470	Casio	EX-Z1200
1872	Casio	EX-Z150
2016	Casio	EX-Z19
2374	Casio	EX-Z2
2474	Casio	EX-Z2000
2169	Casio	EX-Z21
2178	Casio	EX-Z22
2617	Casio	EX-Z2300
1963	Casio	EX-Z250
2120	Casio	EX-Z270 / Z280
3173	Casio	EX-Z28
467	Casio	EX-Z3
468	Casio	EX-Z30
1964	Casio	EX-Z300
2509	Casio	EX-Z330
2644	Casio	EX-Z350
469	Casio	EX-Z40
2088	Casio	EX-Z400
2264	Casio	EX-Z450
1007	Casio	EX-Z5
470	Casio	EX-Z50
477	Casio	EX-Z500
471	Casio	EX-Z55
2488	Casio	EX-Z550
472	Casio	EX-Z57
1194	Casio	EX-Z6
891	Casio	EX-Z60
890	Casio	EX-Z600
1236	Casio	EX-Z65
3174	Casio	EX-Z690
1192	Casio	EX-Z7
1195	Casio	EX-Z70
1062	Casio	EX-Z700
1294	Casio	EX-Z75
473	Casio	EX-Z750
1523	Casio	EX-Z77
1738	Casio	EX-Z80
2620	Casio	EX-Z800
1962	Casio	EX-Z85
889	Casio	EX-Z850
1830	Casio	EX-Z9
2265	Casio	EX-Z90

2618	Casio	EX-ZR10
2744	Casio	EX-ZR100
3117	Casio	EX-ZR15
3175	Casio	EX-ZR20
3116	Casio	EX-ZR200
3523	Casio	EX-ZR700
2892	Casio	EX-ZS10
3020	Casio	EX-ZS100
3176	Casio	EX-ZS12
3019	Casio	EX-ZS15
3177	Casio	EX-ZS150
3334	Casio	Exilim EX-H50
3333	Casio	Exilim EX-N1 / N10 / N20
3337	Casio	Exilim EX-ZR1000
3336	Casio	Exilim EX-ZR300
3335	Casio	Exilim EX-ZS200
479	Casio	QV-R40
480	Casio	QV-R41
481	Casio	QV-R51-52-61
482	Casio	QV-R62
3833	CAT	B100
4040	CAT	B15Q
3156	CAT	Cat Nova
3533	CAT	CatB15
4289	CAT	S30
4636	CAT	S31
4108	CAT	S40
4622	CAT	S41
4109	CAT	S50
4288	CAT	S60
1354	Clarion	Map 360
1355	Clarion	Map 370
1356	Clarion	Map 560
1357	Clarion	Map 670
1358	Clarion	Map 770
3347	Clarion	NX501E 6,2
1137	Clarion	VMA 8582
1146	Clarion	VRX 633R
971	COWON	Audio X5L
2369	COWON	S9
2814	CTL	2goPC Slate
3901	Cube 1	G503
1926	Daewoo NaviCat	DPN-35xx
1927	Daewoo NaviCat	DPN-43xx
4083	DeLorme inReach	Explorer (Satellitentelefon)
1359	Delphi Grundig	Nav 100
1360	Delphi Grundig	Nav 210e

1361	Delphi Grundig	Nav 210w
4353	Donjey	DJ22-120
2284	doro	HandleEasy 330gsm
2939	doro	HandleEasy 332gs
3875	doro	Liberto 810
4011	doro	Liberto 820
3990	doro	PhoneEasy 508-†
3269	doro	PhoneEasy 515
3536	doro	PhoneEasy 605 GSM
3746	doro	PhoneEasy 612
2046	E-Ten	Glofiish M800
2288	E-Ten	Glofiish X500
2194	E-Ten	Glofiish X610
2110	E-Ten	Glofiish X800
2500	ECTACO	jetBook Lite
2941	Emporia	ELEGANCE
2021	Emporia	Life Plus
3091	Emporia	Safety Plus
2816	Emporia	TALK Premium
1831	Emporia	Time Seniorenhandy V30
483	Epson	L-500V
259	Epson	P-2000
1822	Epson	P-5000
2144	Epson	P-7000
3766	FairPhone	Fairphone 1
4359	FairPhone	Fairphone 2
1476	Falk	E30 / E60 / N100 / N150
2051	Falk	F10/F10 Silver Edition
2243	Falk	F12
1769	Falk	F3
2052	Falk	F4-/F6-/F8-2nd
1770	Falk	F5
1771	Falk	F8
1767	Falk	M4
1768	Falk	M6 / M8
1475	Falk	N220L / N240L
1143	Falk	N30/40/80/120/200
1142	Falk	Navigator 7000 PRO SG
3768	Falk	Neo 520 LMU
1484	Falk	P300
1189	Falk	S100/120
2527	Falk	Vision 500/700
1314	fitage	Katharina das Gro./üe
484	Fujifilm	Digital Q1
486	Fujifilm	FinePix 2600 Zoom
487	Fujifilm	FinePix A120
488	Fujifilm	FinePix A310

489	Fujifilm	FinePix A330
491	Fujifilm	FinePix A340
490	Fujifilm	FinePix A345
492	Fujifilm	FinePix A370
911	Fujifilm	FinePix A400
912	Fujifilm	FinePix A500
913	Fujifilm	FinePix A600
1317	Fujifilm	FinePix A610
1047	Fujifilm	FinePix A700
1255	Fujifilm	FinePix A820/A900
2907	Fujifilm	FinePix AV110
2754	Fujifilm	FinePix AV200
2753	Fujifilm	FinePix AX300
493	Fujifilm	FinePix E500
494	Fujifilm	FinePix E510
495	Fujifilm	FinePix E550
791	Fujifilm	FinePix E900
496	Fujifilm	FinePix F10
1730	Fujifilm	FinePix F100fd
817	Fujifilm	FinePix F11
1050	Fujifilm	FinePix F20
2112	Fujifilm	FinePix F200EXR
909	Fujifilm	FinePix F30
2629	Fujifilm	FinePix F300EXR
497	Fujifilm	FinePix F401
1257	Fujifilm	FinePix F40fd
498	Fujifilm	FinePix F420
485	Fujifilm	FinePix F440
499	Fujifilm	FinePix F440/F450
500	Fujifilm	FinePix F455
792	Fujifilm	FinePix F460
910	Fujifilm	FinePix F470
1598	Fujifilm	FinePix F47fd
1601	Fujifilm	Finepix F480
2746	Fujifilm	FinePix F500EXR
1597	Fujifilm	FinePix F50fd
2747	Fujifilm	FinePix F550EXR
3021	Fujifilm	FinePix F600EXR
501	Fujifilm	FinePix F601
1960	Fujifilm	FinePix F60fd
502	Fujifilm	FinePix F610
1025	Fujifilm	FinePix F650
3125	Fujifilm	FinePix F660
3471	Fujifilm	FinePix F660EXR
503	Fujifilm	FinePix F700
2256	Fujifilm	FinePix F70EXR
504	Fujifilm	FinePix F710

3341	Fujifilm	FinePix F750EXR
3126	Fujifilm	FinePix F770
3342	Fujifilm	FinePix F800EXR
2423	Fujifilm	FinePix F80EXR
505	Fujifilm	FinePix F810
2424	Fujifilm	FinePix HS10
2834	Fujifilm	FinePix HS20EXR
3124	Fujifilm	FinePix HS30
1729	Fujifilm	FinePix J10
1974	Fujifilm	FinePix J150w
2109	Fujifilm	FinePix J20
2373	Fujifilm	FinePix J25
2943	Fujifilm	FinePix J37
1731	Fujifilm	FinePix J50
2420	Fujifilm	FinePix JV100
2751	Fujifilm	FinePix JV200
2421	Fujifilm	FinePix JX200
3132	Fujifilm	FinePix JX250
2752	Fujifilm	FinePix JX300
2750	Fujifilm	FinePix JX350
3022	Fujifilm	FinePix JX370
3131	Fujifilm	FinePix JX500
3133	Fujifilm	FinePix JX520
3130	Fujifilm	FinePix JX580
3129	Fujifilm	FinePix JZ250
2422	Fujifilm	FinePix JZ500
506	Fujifilm	FinePix M603
507	Fujifilm	FinePix MX2900
2523	Fujifilm	FinePix Real 3D W1
2627	Fujifilm	FinePix Real 3D W3
4013	Fujifilm	FinePix S1
1733	Fujifilm	FinePix S1000fd
1732	Fujifilm	FinePix S100FS
2257	Fujifilm	FinePix S1500
2113	Fujifilm	FinePix S1500
2436	Fujifilm	FinePix S1800
508	Fujifilm	FinePix S2 Pro
509	Fujifilm	FinePix S20 Pro
2255	Fujifilm	FinePix S2000hd
1973	Fujifilm	FinePix S2000hd
2308	Fujifilm	FinePix S200EXR
2630	Fujifilm	FinePix S2800HD
2833	Fujifilm	FinePix S2950
510	Fujifilm	FinePix S3 Pro
2986	Fujifilm	FinePix S3300
511	Fujifilm	FinePix S3500
2837	Fujifilm	FinePix S4000

3127	Fujifilm	FinePix S4200
1600	Fujifilm	FinePix S5 Pro
512	Fujifilm	FinePix S5000
914	Fujifilm	FinePix S520
513	Fujifilm	FinePix S5500
793	Fujifilm	FinePix S5600
1254	Fujifilm	FinePix S5700
1602	Fujifilm	FinePix S5800
514	Fujifilm	FinePix S602
1049	Fujifilm	FinePix S6500 fd
515	Fujifilm	FinePix S7000
1603	Fujifilm	FinePix S8000fd
1734	Fujifilm	FinePix S8100fd
517	Fujifilm	FinePix S9500/S9000
1048	Fujifilm	FinePix S9600
3122	Fujifilm	FinePix SL300
2749	Fujifilm	FinePix T200
2835	Fujifilm	FinePix T300
3123	Fujifilm	FinePix T400
908	Fujifilm	FinePix V10
3178	Fujifilm	FinePix X Pro 1
3343	Fujifilm	FinePix X-E1
3003	Fujifilm	FinePix X10/X20
2899	Fujifilm	FinePix X100/X100S
4702	Fujifilm	Finepix XP120
2836	Fujifilm	FinePix XP30
3128	Fujifilm	FinePix XS1
516	Fujifilm	FinePix Z1/Z2/Z3
1736	Fujifilm	FinePix Z100
1599	Fujifilm	FinePix Z100fd
1604	Fujifilm	FinePix Z10fd
1735	Fujifilm	FinePix Z20fd
2258	Fujifilm	FinePix Z300
2427	Fujifilm	FinePix Z300
2111	Fujifilm	FinePix Z33WP
2259	Fujifilm	FinePix Z35
2260	Fujifilm	FinePix Z37
1256	Fujifilm	FinePix Z5fd
2425	Fujifilm	FinePix Z70
2426	Fujifilm	FinePix Z700EXR
2628	Fujifilm	FinePix Z800
2748	Fujifilm	FinePix Z90
2934	Fujifilm	FinePix Z900EXR
3004	Fujifilm	FinePix Z950EXR
4389	Fujifilm	GFX 50s
3436	Fujifilm	HS50EXR
4180	Fujifilm	X 70

3664	Fujifilm	X-A1	
4355	Fujifilm	X-A10	
4278	Fujifilm	X-A3 / X-A5	
3663	Fujifilm	X-E1	
3729	Fujifilm	X-E2 / X-E2S	
4623	Fujifilm	X-E3	
3316	Fujifilm	X-F1	
3642	Fujifilm	X-M1	
4179	Fujifilm	X-Pro 2	
3767	Fujifilm	X-T1	
4079	Fujifilm	X-T10 / X-T20	
4257	Fujifilm	X-T2 / X-H1	
4363	Fujifilm	X100F	
3928	Fujifilm	X100T	
3927	Fujifilm	X30	
3727	Fujifilm	XQ1	
4222	Fujitsu	Arrows M305	
347	Fujitsu Siemens	LOOX 400	
348	Fujitsu Siemens	LOOX 410	
349	Fujitsu Siemens	LOOX 420	
350	Fujitsu Siemens	LOOX 600	
351	Fujitsu Siemens	LOOX 610	
352	Fujitsu Siemens	LOOX 700	
353	Fujitsu Siemens	LOOX 710	
354	Fujitsu Siemens	LOOX 720	
1449	Fujitsu Siemens	LOOX 830	
1343	Fujitsu Siemens	LOOX N100/N110	
1126	Fujitsu Siemens	LOOX N500	
1336	Fujitsu Siemens	LOOX N520	
2240	Garmin	1390Tpro	
260	Garmin		3600
1078	Garmin	60C/60CS	
1171	Garmin	60Cx/60CSx	
1818	Garmin	Colorado 300	
2498	Garmin	Dakota 20	
2477	Garmin	Edge 605	
2878	Garmin	Edge 705	
2832	Garmin	Edge 800/810	
3227	Garmin	eTrex 30	
2360	Garmin	eTrex Legend HCx	
1584	Garmin	etrex Venture Cx	
4360	Garmin	Fenix 5 / 5X	
4361	Garmin	Fenix 5S	
1318	Garmin	Forerunner 101/201/301	
1319	Garmin	Forerunner 205/305	
4364	Garmin	Forerunner 35	
261	Garmin	Geko 101/201/301	

262	Garmin	GPSmap 276C
2720	Garmin	GPSmap 62s
3109	Garmin	Montana
4621	Garmin	Montana 610
2236	Garmin	nuevi 1240
2239	Garmin	nuevi 1350T
3633	Garmin	Nuevi 140 LMT
2219	Garmin	nuevi 1490T
2242	Garmin	nuevi 1490Tpro
2869	Garmin	nuevi 1690 n./°Link
1362	Garmin	nuevi 200
1845	Garmin	nuevi 200W
2234	Garmin	nuevi 205CT
1762	Garmin	nuevi 205W
3236	Garmin	nuevi 2360
3041	Garmin	nuevi 2460LMT / 2495LMT
1363	Garmin	nuevi 250
1485	Garmin	nuevi 250W
3540	Garmin	Nuevi 2545 LT
2168	Garmin	nuevi 255T
2235	Garmin	nuevi 255T / 265T
1763	Garmin	nuevi 255W
2238	Garmin	nuevi 255WT / 265WT
3154	Garmin	nuevi 2595LMT
1364	Garmin	nuevi 270
1764	Garmin	nuevi 275W
1365	Garmin	nuevi 300 de Luxe
1167	Garmin	nuevi 300-310-350-360-370
3209	Garmin	nuevi 3490LMT
1366	Garmin	nuevi 350T
3541	Garmin	Nuevi 3590 LMT
3246	Garmin	nuevi 3590 LMT
3547	Garmin	nuevi 3597 LMT
1367	Garmin	nuevi 360T
2706	Garmin	nuevi 3790T
1761	Garmin	nuevi 5000
2233	Garmin	nuevi 550 Allround
1326	Garmin	nuevi 600/610/650/660/670/680
1756	Garmin	nuevi 710
1757	Garmin	nuevi 750
2241	Garmin	nuevi 755 / 765 / 775
1758	Garmin	nuevi 770
1759	Garmin	nuevi 860
1760	Garmin	nuevi 900
2676	Garmin	nuevifone A10
2667	Garmin	nuevifone A50
2492	Garmin	nuevifone G60

2497	Garmin	nuevifone M10
4351	Garmin	n√°vi 2599
2012	Garmin	Oregon 200/300/400t
2575	Garmin	Oregon 450t
3866	Garmin	Oregon 600
263	Garmin	Quest
1168	Garmin	StreetPilot 2610
1095	Garmin	StreetPilot 2820
1368	Garmin	StreetPilot 7200
1369	Garmin	StreetPilot 7500
1307	Garmin	StreetPilot c510 de Luxe
1130	Garmin	StreetPilot c550
265	Garmin	Vista
3653	Garmin	Zumo 390LM
4477	Garmin	Zumo 395
1370	Garmin	Zumo 400
1371	Garmin	Zumo 500
2232	Garmin	zumo 550
1372	Garmin	Zumo 550
2172	Garmin	Zumo 660
2237	Garmin	zumo 660
1298	General Imaging	A730/A830
1967	General Imaging	A735/A835/A1235
1300	General Imaging	E1030
1968	General Imaging	E1035
1299	General Imaging	E1040/E850
1880	General Imaging	E1050
1301	General Imaging	E1240
1969	General Imaging	E840 S
1278	General Imaging	G1
1966	General Imaging	G2
2962	General Imaging	X5
4757	Gigaset	850A
4174	Gigaset	ME
2089	Google	G1
3701	Google	Nexus 5 (ALT)
2524	Google	Nexus One
4290	Google	Pixel
4469	Google	Pixel - CASEFIT
4598	Google	Pixel 2
4616	Google	Pixel 2 - CASEFIT
4599	Google	Pixel 2 XL
4618	Google	Pixel 2 XL - CASEFIT
4291	Google	Pixel XL
4471	Google	Pixel XL - CASEFIT
3751	GoPro	Hero 3+
3496	GoPro	Hero 3, LCD Display

3513	GoPro	Hero 3, nur f. Linse	
4169	GoPro	Hero 4	
4309	GoPro	Hero 4 Session / Hero 5 Session	
4308	GoPro	Hero 5	
1486	Harman Kardon	GPS 500	
4398	Hasselblad	X1D-50c	
3469	Hero	H2000+	
518	Hewlett Packard		215
519	Hewlett Packard		320
520	Hewlett Packard		620
2872	Hewlett Packard		625
521	Hewlett Packard		735
522	Hewlett Packard		850
523	Hewlett Packard		935
524	Hewlett Packard		945
4324	Hewlett Packard	Elite X3	
2321	Hewlett Packard	iPAQ 214 Enterprise Handheld	
389	Hewlett Packard	iPAQ 4100	
1642	Hewlett Packard	iPAQ 514 Voice Messenger	
367	Hewlett Packard	iPAQ h1900	
368	Hewlett Packard	iPAQ h1910	
369	Hewlett Packard	iPAQ h1915	
370	Hewlett Packard	iPAQ h1920	
371	Hewlett Packard	iPAQ h1930	
372	Hewlett Packard	iPAQ h1935	
373	Hewlett Packard	iPAQ h1937	
374	Hewlett Packard	iPAQ h1940	
375	Hewlett Packard	iPAQ h1945	
376	Hewlett Packard	iPAQ h2210	
377	Hewlett Packard	iPAQ h2215	
378	Hewlett Packard	iPAQ h3600	
379	Hewlett Packard	iPAQ h3630	
380	Hewlett Packard	iPAQ h3660	
381	Hewlett Packard	iPAQ h3715	
382	Hewlett Packard	iPAQ h3760	
383	Hewlett Packard	iPAQ h3800	
384	Hewlett Packard	iPAQ h3835	
385	Hewlett Packard	iPAQ h3850	
386	Hewlett Packard	iPAQ h3950	
387	Hewlett Packard	iPAQ h3955	
388	Hewlett Packard	iPAQ h3970	
390	Hewlett Packard	iPAQ h4110	
391	Hewlett Packard	iPAQ h4115	
392	Hewlett Packard	iPAQ h4150	
393	Hewlett Packard	iPAQ h4155	
395	Hewlett Packard	iPAQ h4350	
396	Hewlett Packard	iPAQ h4355	

394	Hewlett Packard	iPAQ h4705	
1587	Hewlett Packard	iPAQ h5550	
1154	Hewlett Packard	iPAQ hw6915	
397	Hewlett Packard	iPAQ hx2410	
398	Hewlett Packard	iPAQ hx2750	
399	Hewlett Packard	iPAQ hx4700	
525	Hewlett Packard	PhotoSmart R507	
526	Hewlett Packard	PhotoSmart R707	
1965	Hewlett Packard	PhotoSmart R725	
1234	Hewlett Packard	PhotoSmart R727	
1208	Hewlett Packard	PhotoSmart R817	
1649	Hewlett Packard	PhotoSmart R927	
1235	Hewlett Packard	PhotoSmart R967	
1373	Hewlett Packard	RX 5720	
1374	Hewlett Packard	RX 5935	
2965	Hewlett Packard	Veer	
2215	Hewlett Packard	Voice Messenger	
4790	Honor		10
4791	Honor	10 - CASEFIT	
4749	Honor	7X	
4750	Honor	7X - CASEFIT	
4686	Honor	View 10	
4687	Honor	View 10 - CASEFIT	
4203	HTC	10 / One M10	
4317	HTC	10 Evo	
2700	HTC	7 Mozart	
2811	HTC	7 Pro	
2688	HTC	7 Trophy	
3351	HTC	8S	
3326	HTC	8x (nur/only Plus)	
1216	HTC	Advantage X7500	
3623	HTC	Butterfly *	
2926	HTC	ChaCha	
1173	HTC	Charmer	
2481	HTC	Desire	
4762	HTC	Desire 12	
4763	HTC	Desire 12 - CASEFIT	
4759	HTC	Desire 12 Plus†	
4760	HTC	Desire 12 Plus - CASEFIT	
3707	HTC	Desire 200	
4020	HTC	Desire 300	
3824	HTC	Desire 310	
3575	HTC	Desire 500	
3957	HTC	Desire 510	
4213	HTC	Desire 526G	
4184	HTC	Desire 530	
3752	HTC	DEsire 601	

3841	HTC	Desire 610
3874	HTC	Desire 816
4107	HTC	Desire 820
4312	HTC	Desire 825
3277	HTC	Desire C
2669	HTC	Desire HD
2873	HTC	Desire S
3713	HTC	Desire SV
3330	HTC	Desire X
2686	HTC	Desire Z
2960	HTC	EVO 3D
3085	HTC	Explorer
2866	HTC	Gratia
2485	HTC	HD mini
2355	HTC	HD2 Leo
2699	HTC	HD7
2306	HTC	Hero
2822	HTC	Incredible S
2468	HTC	Legend
2160	HTC	Magic
3405	HTC	One
4156	HTC	One A9
4274	HTC	One A9S
3794	HTC	One M8
3999	HTC	One M9
3705	HTC	One Max
3574	HTC	One mini
3830	HTC	One mini 2
3225	HTC	One S
3399	HTC	One SV
3231	HTC	One V
3224	HTC	One X (nur/only Plus)
3370	HTC	One X L (nur/only Plus)
3356	HTC	One X Plus (nur/only Plus)
2208	HTC	P3470
2494	HTC	P4350
1709	HTC	P6500
3057	HTC	Radar
3086	HTC	Rhyme
1808	HTC	S710
2157	HTC	S740
2961	HTC	Salsa
2910	HTC	Sensation (nur/only Plus)
3076	HTC	Sensation XE (nur/only Plus)
3063	HTC	Sensation XL
2537	HTC	Smart
2339	HTC	Snap 520

2352	HTC	Tattoo
3078	HTC	TITAN
1637	HTC	Touch
2053	HTC	Touch 3G
1673	HTC	Touch Cruise
2590	HTC	Touch Cruise2 (O2 Guide)
1851	HTC	Touch Diamond
2158	HTC	Touch Diamond II
1652	HTC	Touch Dual
2043	HTC	Touch HD
2029	HTC	Touch Pro
2193	HTC	Touch Pro2
2334	HTC	Touch2
1174	HTC	TyTN
1743	HTC	TyTN II (Kayser)
4338	HTC	U Play
4449	HTC	U Play - CASEFIT
4337	HTC	U Ultra
4447	HTC	U Ultra - CASEFIT
4444	HTC	U11
4445	HTC	U11 - CASEFIT
4645	HTC	U11 Life
4646	HTC	U11 Life - CASEFIT
4674	HTC	U11 Plus
4675	HTC	U11 Plus - CASEFIT
4787	HTC	U12 Plus
4788	HTC	U12 Plus - CASEFIT
1175	HTC	Universal
3247	HTC	Velocity 4G
2883	HTC	Viva
2541	HTC	Wildfire
2895	HTC	Wildfire S
4716	Huawei	P SMART
3376	Huawei	Ascend G300 U8815
3595	Huawei	Ascend G330
3500	Huawei	Ascend G510
3629	Huawei	Ascend G525
4173	Huawei	Ascend G526
3860	Huawei	Ascend G6
3594	Huawei	Ascend G600
3566	Huawei	Ascend G615
3949	Huawei	Ascend G620 / G620s
3859	Huawei	Ascend G630
4094	Huawei	Ascend G7
3656	Huawei	Ascend G700
3877	Huawei	Ascend G740
3919	Huawei	Ascend G750

3709	Huawei	Ascend Mate
3275	Huawei	Ascend P1
3526	Huawei	Ascend P6
3527	Huawei	Ascend P6 Fullbody Premium
3842	Huawei	Ascend P7
3876	Huawei	Ascend P7 mini
3509	Huawei	Ascend W1†
3511	Huawei	Ascend W1 Fullbody nur Plus
3383	Huawei	Ascend Y 201 Pro
3253	Huawei	Ascend Y200
3464	Huawei	Ascend Y300
3819	Huawei	Ascend Y330
3775	Huawei	Ascend Y530
3950	Huawei	Ascend Y550
3046	Huawei	Boulder U8350
3013	Huawei	Dual-Sim G6608
3867	Huawei	G610
4130	Huawei	G8 / GX8
4347	Huawei	Honor 5C
4348	Huawei	Honor 5X
4582	Huawei	Honor 6A
4349	Huawei	Honor 6X
4459	Huawei	Honor 6X - CASEFIT
4110	Huawei	Honor 7
4346	Huawei	Honor 8
4451	Huawei	Honor 8 - CASEFIT
4511	Huawei	Honor 9
4512	Huawei	Honor 9 - CASEFIT
3232	Huawei	Honour U8860
2879	Huawei	IDEOS U8150
2974	Huawei	IDEOS X1 / U8180
3009	Huawei	IDEOS X3 / U8510
2876	Huawei	IDEOS X5 / U8800
4273	Huawei	Nova
4575	Huawei	Nova 2
4576	Huawei	Nova 2 - CASEFIT
4717	Huawei	P SMART - CASEFIT
4400	Huawei	P10
4343	Huawei	P10 - CASEFIT
4402	Huawei	P10 lite
4345	Huawei	P10 lite - CASEFIT
4401	Huawei	P10 Plus
4344	Huawei	P10 Plus - CASEFIT
4727	Huawei	P20†
4728	Huawei	P20 - CASEFIT
4730	Huawei	P20 lite
4731	Huawei	P20 lite - CASEFIT

4733	Huawei	P20 Pro
4734	Huawei	P20 Pro - CASEFIT
4001	Huawei	P8
4064	Huawei	P8 lite (2015)
4339	Huawei	P8 lite (2017)
4393	Huawei	P8 lite (2017) - CASEFIT
4185	Huawei	P9
4186	Huawei	P9 lite
4710	Huawei	P9 Lite Mini-†
4709	Huawei	P9 Lite Mini - CASEFIT
4212	Huawei	P9 Plus
3047	Huawei	Sonic U8650
2923	Huawei	U8100
2668	Huawei	U8230
3097	Huawei	U8850 Vision (nur/only Plus)
4139	Huawei	Y6
4583	Huawei	Y6 (2017)
4510	Huawei	Y6 II compact
4150	Huawei	Y625
4092	Huawei	Y635
4549	Huawei	Y7
4550	Huawei	Y7 - CASEFIT
3590	i-INN	Malata
3591	i-INN	Malata 8.0 MP
3410	i-INN	Smartlet
243	i-mate	JAM
969	i-mate	K-JAM
244	i-mate	PDA2
245	i-mate	PDA2k
246	i-mate	PPC
2289	Jenoptik	JD 10,0 z3DC
527	Jenoptik	JD 3.3 xz3
290	JVC	GR-D225EX
291	JVC	GR-DVL9800
292	JVC	GZ-MC200
293	JVC	GZ-MC500
2056	JVC	GZ-MG 330
2049	JVC	GZ-MG575
974	JVC	KD-AVX1
1458	JVC	KD-AVX2
1375	JVC	KV-PX 70
3945	Kazam	Trooper 2 5.0
3946	Kazam	Trooper X5.0
1955	Kodak	C1013
528	Kodak	C300
529	Kodak	C330
530	Kodak	C340

531	Kodak	C360
883	Kodak	C533
1263	Kodak	C613/C713/C813
884	Kodak	C643
882	Kodak	C663
1107	Kodak	C743
1106	Kodak	C875
1956	Kodak	C913
534	Kodak	CX6230
556	Kodak	CX6330
536	Kodak	CX7220
537	Kodak	CX7330
538	Kodak	CX7430
547	Kodak	DCS Pro 14N
548	Kodak	DCS Pro SLR c
551	Kodak	DX4330
532	Kodak	DX4530
533	Kodak	DX6440
535	Kodak	DX6490
549	Kodak	DX7590
550	Kodak	DX7630
3621	Kodak	Easyshare M340
553	Kodak	EasyShare One
552	Kodak	LS633
555	Kodak	LS755
1684	Kodak	M1033
1953	Kodak	M1053
1952	Kodak	M1063
1951	Kodak	M1073 IS
1950	Kodak	M1093 IS
2858	Kodak	M575
2935	Kodak	M580
1527	Kodak	M753
1528	Kodak	M853
1954	Kodak	M863
1525	Kodak	M873
1526	Kodak	M883
2015	Kodak	M893 IS
1108	Kodak	P712
545	Kodak	P850
546	Kodak	P880
1259	Kodak	V1003
1683	Kodak	V1073 / V1273
1529	Kodak	V1233
1530	Kodak	V1253
544	Kodak	V530
543	Kodak	V550

887	Kodak	V570
886	Kodak	V603
1109	Kodak	V610
1105	Kodak	V705
1260	Kodak	V803
1685	Kodak	Z1012 IS
1948	Kodak	Z1015 IS
1531	Kodak	Z1275
885	Kodak	Z612
554	Kodak	Z650
539	Kodak	Z700
1341	Kodak	Z710
1262	Kodak	Z712 IS
540	Kodak	Z730
541	Kodak	Z740
542	Kodak	Z7590
1532	Kodak	Z812 IS
1949	Kodak	Z8612 IS
1261	Kodak	Z885
1533	Kodak	Z885
2867	Kodak	Z981
1534	Kodak	ZD710 HD
557	Konica Minolta	400Z
558	Konica Minolta	420z
559	Konica Minolta	500z
560	Konica Minolta	A200
561	Konica Minolta	Dimage 3200
562	Konica Minolta	Dimage 7
563	Konica Minolta	Dimage 7Hi
564	Konica Minolta	Dimage 7i
565	Konica Minolta	Dimage A1
566	Konica Minolta	Dimage A2
568	Konica Minolta	Dimage F300
569	Konica Minolta	Dimage X20
570	Konica Minolta	Dimage Xi
572	Konica Minolta	Dynax 5D
571	Konica Minolta	Dynax 7
573	Konica Minolta	Dynax 7D
574	Konica Minolta	E50
575	Konica Minolta	G400
576	Konica Minolta	G530
577	Konica Minolta	G600
578	Konica Minolta	S304
579	Konica Minolta	S414
582	Konica Minolta	X1
580	Konica Minolta	X50
581	Konica Minolta	X60

	584	Konica Minolta	XG
	585	Konica Minolta	Z1
	587	Konica Minolta	Z10
	588	Konica Minolta	Z20
	589	Konica Minolta	Z3
	590	Konica Minolta	Z5
	591	Konica Minolta	Z6
	1581	Kr	RC-3
	1765	Kr	RC-4X
	592	Kyocera	L3v
	593	Kyocera	L4v
	3731	Leica	C
4027L		Leica	C-Lux (Typ 1546)
	1014	Leica	C-LUX 1
	1258	Leica	C-LUX 2
	2000	Leica	C-LUX 3
	4670	Leica	CL (Typ 7323)
	594	Leica	D-LUX
	3959	Leica	D-LUX (Typ 109)
	956	Leica	D-LUX 2
	1197	Leica	D-LUX 3
	1984	Leica	D-LUX 4
	2673	Leica	D-LUX 5
	3359	Leica	D-Lux 6
	595	Leica	Digilux 1
	596	Leica	Digilux 2
	1198	Leica	Digilux 3
	597	Leica	Digital Zoom
	598	Leica	Digitalmodul DMR
	4116	Leica	Leica Q
	3418	Leica	M Typ (240) / M-P
	4354	Leica	M10
	1115	Leica	M8
	2292	Leica	M8.2
	2293	Leica	M9
	2295	Leica	S2
	4144	Leica	SL
	3910	Leica	T / TL
	4112	Leica	V Lux (Typ 114)-†
	2697	Leica	V-LUX 2
	2514	Leica	V-LUX 20
	2919	Leica	V-LUX 30
	3357	Leica	V-lux 4
	3358	Leica	V-lux 40
	3616	Leica	X Vario
	2294	Leica	X1 / X2
	4330	Lenovo	Moto G4

4294	Lenovo	Moto G4 Plus	
4375	Lenovo	Moto G5	
4376	Lenovo	Moto G5 Plus	
4419	Lenovo	Moto Z	
4420	Lenovo	Moto Z Play	
3617	Lenovo	Smart Tab II-†	
3888	Lenovo	T440s	
4103	Lenovo	T450s	
4111	Lenovo	ThinkVision Pro2840m	
3996	Lenovo	Yoga 2 10.1	
4211	Lenovo	Yoga 260	
4132	Lenovo	Yoga Pro 3	
3744	Lenovo	Yoga Tablet 10	
3759	Lenovo	Yoga Tablet 8	
3719	LG	Optimius G pro	
247	LG		2050
248	LG		8120
2319	LG	BL20 newchocolate	
2354	LG	BL40 newchocolate	
4032	LG	C 70 Spirit	
249	LG	C1200	
250	LG	C2200	
2810	LG	C320 (nur/only Plus)	
251	LG	C3300	
963	LG	C3310	
2908	LG	C550 Optimus Chat	
3234	LG	E400 Optimus L3	
3553	LG	E430 Optimus L3 II Smartphone	
3672	LG	E440 Optimus L4 2	
3552	LG	E460 Optimus L5 II Smartphone	
3058	LG	E510 Optimus Hub	
3278	LG	E610 Optimus L5	
2911	LG	E720 Optimus Chic	
3077	LG	E730 Optimus Sol	
2698	LG	E900 Optimus 7	
3393	LG	E906 Jil Sander	
3395	LG	E975 Optimus G	
859	LG	F2300	
860	LG	F3000	
3960	LG	F60	
3853	LG	F70	
3887	LG	G Flex	
4065	LG	G Flex 2	
3792	LG	G Pro Lite	
3685	LG	G2	
3823	LG	G2 mini	
3861	LG	G3	

3951	LG	G3s
4000	LG	G4
4159	LG	G4 Stylus
4053	LG	G4c
4098	LG	G4s
4175	LG	G5 / G5 SE
4380	LG	G6
4776	LG	G7
4777	LG	G7 - CASEFIT
2555	LG	GB102
2182	LG	GC900 Viewty smart
2363	LG	GD510
2493	LG	GD880 MINI
2206	LG	GD900 Crystal
2578	LG	GM360 Viewty Plus
2331	LG	GM750
2663	LG	GS101
2506	LG	GS290 Cookie Fresh
2550	LG	GS500
2672	LG	GT350
2660	LG	GT400 Viewty Smile
2705	LG	GT405
2340	LG	GT500
2482	LG	GT505 Pathfinder
2554	LG	GT540
2544	LG	GU230
2388	LG	GW300 (nur/only Plus)
2504	LG	GW520 Etna
2469	LG	GW620
2804	LG	GX500 DualSim
1836	LG	HB620-T Elbrus
4177	LG	K10 (2016)
4383	LG	K10 (2017)
4438	LG	K10 (2017) - CASEFIT
4772	LG	K11
4773	LG	K11 - CASEFIT
4176	LG	K4 (2016)
4381	LG	K4 (2017)
4277	LG	K7
4182	LG	K8 (2016)
4382	LG	K8 (2017)
4437	LG	K8 (2017) - CASEFIT
2184	LG	KB770
2001	LG	KC550
2017	LG	KC910 Renoir
1632	LG	KE500
1450	LG	KE850 Prada

1310	LG	KE970 Shine
1943	LG	KF510
1748	LG	KF600
1862	LG	KF700
1863	LG	KF750 Secret
2024	LG	KF900 Prada II
972	LG	KG800 Chocolate
2057	LG	KM380
2502	LG	KM570 Arena II
2154	LG	KM900 Arena
2050	LG	KP130
2048	LG	KP500
2392	LG	KP501 Cookie
2341	LG	KP502
1814	LG	KS20
2309	LG	KS360
2571	LG	KS365
1339	LG	KU800
1648	LG	KU990 Viewty
2887	LG	KU990i
3987	LG	L 50
3827	LG	L 70
3828	LG	L 90
4002	LG	L Bello
4008	LG	L Fino
3878	LG	L40
3913	LG	L65
1376	LG	LN 710
1377	LG	LN 715
964	LG	M4410
3392	LG	Nexus 4 (nur only Plus)
4097	LG	Nexus 5
3778	LG	Nexus 5 (ALT)
4123	LG	Nexus 5X
3720	LG	Optimius G pro FullBody
3863	LG	Optimus F5
3708	LG	Optimus L9 II
3385	LG	P-936
2826	LG	P350 Optimus Me
2665	LG	P500 Optimus One
3245	LG	P690 Optimus Net
3235	LG	P700 Optimus L7
3548	LG	P710 Optimus L7 II
3259	LG	P720 Optimus 3D Max
961	LG	P7200
3352	LG	P760 Optimus L9
3273	LG	P880 Optimus 4X HD

3354	LG	P895 Optimus Vu
2929	LG	P920 Optimus 3D
3103	LG	P940 Prada 3.0
2897	LG	P970 Optimus Black
2864	LG	P990 Optimus Speed (nur/only Plus)
4572	LG	Q6
4774	LG	Q7
4775	LG	Q7 - CASEFIT
3073	LG	S310
962	LG	S5200
4216	LG	Stylus 2
3325	LG	T 385
2791	LG	T300
2737	LG	T310
2932	LG	T320 Cookie 3D
2909	LG	T500 Ego
3104	LG	T590
979	LG	U8290
4613	LG	V30
4614	LG	V30 - CASEFIT
4207	LG	X cam
4275	LG	X power
4514	LG	X power2
4183	LG	X screen
4055	LG	Y70
1583	Logitech	Harmony 1000
3602	Lytro	Lytro Kamera
1378	Magellan	Crossover GPS
1800	Magellan	RoadMate 1200/1500
1379	Magellan	RoadMate 2200T
1380	Magellan	RoadMate 3000T
1381	Magellan	RoadMate 3050T
1382	Magellan	RoadMate 6000T
981	Magellan	RoadMate 700/800
934	Maginon	DC8300
599	Maginon	Slimline X5 5mio
1570	Maginon	XS 60
3416	Medion	E 3501
1928	Medion	E-3xxx
1929	Medion	E-4xxx
4124	Medion	E5001
1383	Medion	GoPal 210
1384	Medion	GoPal 460
1385	Medion	GoPal 465
1386	Medion	GoPal 470
1387	Medion	GoPal 500
1388	Medion	GoPal 510

1389	Medion	GoPal 515	
1850	Medion	GoPal E4430	
3414	Medion	GoPal E5455	
1856	Medion	GoPAL P4410E	
3850	Medion	GoPal S3877	
3670	Medion	Life E4001	
3579	Medion	Life MD 86641	
3572	Medion	Life Tab P9514	
3675	Medion	LifeTab E10311	
600	Medion	MD 40696	
336	Medion	MD 41258/40885/42592	
339	Medion	MD 41600	
340	Medion	MD 7200	
266	Medion	MD 95000	
341	Medion	MD 95069	
1170	Medion	MD 96050	
1203	Medion	MD 96080/GoPal	
1499	Medion	MD 96220	
907	Medion	MD 96710	
1930	Medion	P-4xxx	
1931	Medion	P-5xxx	
2394	Medion	P4445 / P4440	
337	Medion	PNA 150	
338	Medion	PNA 200	
1933	Medion	S-2xxx	
3045	Medion	Smartphone P4310	
3545	Medion	X 44027	
1932	Medion	X-5xxx	
1577	Merian	scout Navigator	
4067	Microsoft	Lumia 532	
3981	Microsoft	Lumia 535	
4137	Microsoft	Lumia 550	
4047	Microsoft	Lumia 640	
4046	Microsoft	Lumia 640 XL	
4160	Microsoft	Lumia 650	
4135	Microsoft	Lumia 950	
4136	Microsoft	Lumia 950 XL	
601	Minox		4211
955	Minox		5011
948	Minox		6011
936	Minox		6211
602	Minox		6311
935	Minox		8111
1613	Minox	Classic Leica M3 5MP	
1824	Minox	DC 8011	
1112	Minox	DC1011	
1615	Minox	DC1022	

1614	Minox	DC7011
1479	Minox	DC7022
1113	Minox	DC8122
888	Minox	DMP2
1616	Minox	WINDWATCH Pro II
2245	Mio	300 Traffic
2246	Mio	500 Traffic / HF Traffic
1390	Mio	C210
1487	Mio	C220
1488	Mio	C250
1489	Mio	C320
1391	Mio	C510E
1490	Mio	C512C
1491	Mio	C520
1392	Mio	C710
1393	Mio	H610
2248	Mio	M305
2247	Mio	M405
1776	Mio	Moov200
1777	Mio	Moov330
1778	Mio	Moov370
3145	Mio	Spirit 485
2244	Mio	V505 TV
583	Mitac	Mio 168/69
586	Mitac	Mio 268/269
681	Mitac	Mio A201
2058	Mitac	Mio A701
1018	Mitac	Mio P350
207	Mitsubishi	M342i
208	Mitsubishi	M430i
2920	mobilcom-debitel	oneTab
4327	Mobistel	Cynus F10
3453	Mobistel	Cynus F3
3740	Mobistel	Cynus F4
3611	Mobistel	Cynus T1
3472	Mobistel	Cynus T2
3534	Mobistel	Cynus T5
209	Motorola	A1000
212	Motorola	A728
213	Motorola	A780
210	Motorola	A920
242	Motorola	A925
211	Motorola	A925
214	Motorola	Accompli 008
2940	Motorola	ATRIX
2479	Motorola	BACKFLIP
215	Motorola	C450

216	Motorola	C650
2703	Motorola	DEFY
3279	Motorola	DEFY Mini
217	Motorola	E1000
2852	Motorola	E122
218	Motorola	E365
219	Motorola	E398
831	Motorola	E770v
2802	Motorola	ES400
2825	Motorola	EX112
3056	Motorola	FIRE XT
2538	Motorola	FLIPOUT
2984	Motorola	Gleam
1166	Motorola	KRZR K1
1454	Motorola	KRZR K3
832	Motorola	L6
1453	Motorola	MAXX V6
2368	Motorola	Milestone
2666	Motorola	Milestone 2
2661	Motorola	Milestone XT720
4167	Motorola	Moto 360 2nd Gen.
4571	Motorola	Moto C
4570	Motorola	Moto C Plus
3835	Motorola	Moto E
4566	Motorola	Moto E4 Plus
4567	Motorola	Moto E4 Plus - CASEFIT
3721	Motorola	Moto G
3924	Motorola	Moto G 2nd Generation
4105	Motorola	Moto G 3rd Generation
4624	Motorola	Moto G5s
4625	Motorola	Moto G5s - CASEFIT
4667	Motorola	Moto G5s Plus
4668	Motorola	Moto G5s Plus - CASEFIT
1861	Motorola	MOTO U9
3753	Motorola	Moto X
3938	Motorola	Moto X 2nd Generation
4157	Motorola	Moto X Force (Droid Turbo 2)
4568	Motorola	Moto Z2 Play
4569	Motorola	Moto Z2 Play - CASEFIT
1465	Motorola	MOTOFONE F3
3229	Motorola	MOTOLUXE XT615
1177	Motorola	MotoRIZR Z3
3384	Motorola	Motosmart
220	Motorola	MPX200
221	Motorola	MPX220
222	Motorola	MPX300
4006	Motorola	Nexus 6

223	Motorola	PEBL	
3071	Motorola	RAZR - XT910	
3364	Motorola	RAZR i XT890	
9	Motorola	RAZR V3	
1593	Motorola	Razr2 V8	
2375	Motorola	Razr2 V9	
1665	Motorola	RIZR Z8	
1882	Motorola	ROKR E8	
1594	Motorola	ROKR Z6	
833	Motorola	ROKR1	
1672	Motorola	Sidekick Slide	
843	Motorola	SLVR L7	
1661	Motorola	SLVR L9	
224	Motorola	V150	
225	Motorola	V22	
226	Motorola	V220	
227	Motorola	V300	
846	Motorola	V3i	
829	Motorola	V3x	
235	Motorola	V525	
236	Motorola	V550	
228	Motorola	V551	
229	Motorola	V600	
230	Motorola	V620	
231	Motorola	V635	
232	Motorola	V70	
233	Motorola	V80	
234	Motorola	V980	
1985	Motorola	W180	
1200	Motorola	W220	
3014	Motorola	WILDER	
3018	Motorola	XOOM	
1394	My Guide		3000
1395	My Guide		3100
1396	My Guide		3300
1397	My Guide		4300
1492	My Guide		4400
1876	NavGear	GT 43	
2249	NavGear	GT-50T-3D	
2947	NavGear	GTX-60-3D	
1398	Naviflash		1020
1493	Naviflash		1021
1494	Naviflash		1040
1399	Naviflash		1060
2224	Navigon	14er-Serie	
1782	Navigon		2100
1781	Navigon	2100 max	

1783	Navigon		2110
1780	Navigon	2110 max	
2225	Navigon	24er-Serie	
1400	Navigon		3100
1401	Navigon		3110
2226	Navigon	33 max-Serie	
3394	Navigon	40 Premium / Plus	
2227	Navigon	43 max-Serie	
2220	Navigon	4310 max	
1495	Navigon	5100/5110	
2228	Navigon		6310
2222	Navigon		6350
3163	Navigon	70 Easy / 70 Plus Live	
2682	Navigon	70 Plus / Premium	
1477	Navigon	7000/7000T	
1402	Navigon		7100
1403	Navigon		7110
1779	Navigon		8110
2186	Navigon		8300
2223	Navigon		8410
2520	Navigon		8450
2221	Navigon	8450 Live	
3088	Navigon	92 Premium Live	
1404	Navigon	P9611	
1496	Navigon	Porsche 9611	
2060	Navigon	Transonic 4000	
1139	Navigon	Transonic 5000	
1140	Navigon	Transonic 6000	
1405	Navigon	TS 6000T	
1406	Navigon	TS 7000T	
1136	Navilock	8 Zoll TFT	
1308	Navman	F20	
1407	Navman	F30	
1408	Navman	F40	
1409	Navman	F50	
1145	Navman	iCN 320/330	
1147	Navman	iCN 520	
1009	Navman	iCN 550	
334	Navman	iCN 600	
335	Navman	iCN 630	
1410	Navman	iCN 720	
1129	Navman	iCN 750	
1150	Navman	iDN 3000	
1411	Navman	N20	
1412	Navman	N40i	
1413	Navman	N60i	
1772	Navman	S30 3D	

1773	Navman	S50 3D	
1774	Navman	S70	
1775	Navman	S90i	
1754	NDrive	280R	
1755	NDrive		400
1753	NDrive	G700	
1752	NDrive	G800	
204	NEC	21i	
205	NEC	N400i	
206	NEC	N850	
3551	Neingrenze	5000 T	
1841	Neonode	N2	
3679	Nikon	1 AW1	
3030	Nikon	1 J1 / J2	
3435	Nikon	1 J3	
3926	Nikon	1 J4	
4149	Nikon	1 J5	
3576	Nikon	1 S1	
3367	Nikon	1 V 2	
3029	Nikon	1 V1	
3801	Nikon	1 V3	
3902	Nikon	AW 120 / AW 130	
3028	Nikon	AW100	
603	Nikon	Coolpix 3200	
604	Nikon	Coolpix 4100	
605	Nikon	Coolpix 4600	
606	Nikon	Coolpix 5000	
607	Nikon	Coolpix 5200	
608	Nikon	Coolpix 5400	
609	Nikon	Coolpix 5500	
610	Nikon	Coolpix 5600	
611	Nikon	Coolpix 5700	
612	Nikon	Coolpix 5800	
613	Nikon	Coolpix 5900	
614	Nikon	Coolpix 7600	
616	Nikon	Coolpix 775	
615	Nikon	Coolpix 7900	
617	Nikon	Coolpix 8400	
618	Nikon	Coolpix 8700	
798	Nikon	Coolpix 8800	
620	Nikon	Coolpix 885	
621	Nikon	Coolpix 995	
3639	Nikon	Coolpix A	
4286	Nikon	Coolpix A300	
4316	Nikon	Coolpix A900	
4281	Nikon	Coolpix B500	
4280	Nikon	Coolpix B700	

797	Nikon	Coolpix L1/L101
1246	Nikon	Coolpix L10
2097	Nikon	Coolpix L100
1247	Nikon	Coolpix L11
2448	Nikon	Coolpix L110
1248	Nikon	Coolpix L12
2838	Nikon	Coolpix L120
1535	Nikon	Coolpix L14
1536	Nikon	Coolpix L15
1696	Nikon	Coolpix L16
1794	Nikon	Coolpix L18
2101	Nikon	Coolpix L19
919	Nikon	Coolpix L2
2102	Nikon	Coolpix L20 / L22
2296	Nikon	Coolpix L21
3237	Nikon	Coolpix L25
917	Nikon	Coolpix L3
918	Nikon	Coolpix L4
1104	Nikon	Coolpix L5
1103	Nikon	Coolpix L6
3598	Nikon	CoolPix L610
3184	Nikon	Coolpix L810
3430	Nikon	CoolPix L820/L830
796	Nikon	Coolpix P1/P2
2447	Nikon	Coolpix P100
922	Nikon	Coolpix P3
2842	Nikon	Coolpix P300
3185	Nikon	Coolpix P310/P330/P340
923	Nikon	Coolpix P4
1537	Nikon	Coolpix P50
2839	Nikon	Coolpix P500
1253	Nikon	Coolpix P5000
3186	Nikon	Coolpix P510
1538	Nikon	Coolpix P5100
3422	Nikon	CoolPix P520
1701	Nikon	Coolpix P60
1981	Nikon	Coolpix P6000
2632	Nikon	Coolpix P7000
2994	Nikon	Coolpix P7100
3310	Nikon	CoolPix P7700
3678	Nikon	CoolPix P7800
1825	Nikon	Coolpix P80
2083	Nikon	Coolpix P90
4026	Nikon	Coolpix P900
3428	Nikon	CoolPix S01
3661	Nikon	Coolpix S02
623	Nikon	Coolpix S1

1101	Nikon	Coolpix S10
3074	Nikon	Coolpix S100
2261	Nikon	Coolpix S1000pj
2635	Nikon	Coolpix S1100pj
3027	Nikon	Coolpix S1200pj
624	Nikon	Coolpix S2
1250	Nikon	Coolpix S200
1697	Nikon	Coolpix S210
2103	Nikon	Coolpix S220
2100	Nikon	Coolpix S230
3421	Nikon	CoolPix S2700
794	Nikon	Coolpix S3
2444	Nikon	Coolpix S3000
3420	Nikon	CoolPix S31
2841	Nikon	Coolpix S3100
3809	Nikon	Coolpix S32
3179	Nikon	Coolpix S3300
3503	Nikon	Coolpix S3500
795	Nikon	Coolpix S4
2445	Nikon	Coolpix S4000
2844	Nikon	Coolpix S4100
3024	Nikon	Coolpix S4150
3180	Nikon	Coolpix S4300 / S4400
920	Nikon	Coolpix S5
1252	Nikon	Coolpix S50
1249	Nikon	Coolpix S500
1251	Nikon	Coolpix S50c
1539	Nikon	Coolpix S51
1540	Nikon	Coolpix S510
2840	Nikon	Coolpix S5100
2634	Nikon	Coolpix S5100
1541	Nikon	Coolpix S51c
1842	Nikon	Coolpix S52 / S52c
1795	Nikon	Coolpix S520
3432	Nikon	CoolPix S5200/S7000
1699	Nikon	Coolpix S550
2298	Nikon	Coolpix S570
921	Nikon	Coolpix S6
1980	Nikon	Coolpix S60
1700	Nikon	Coolpix S600
1978	Nikon	Coolpix S610/S610c
2855	Nikon	Coolpix S6100
3025	Nikon	Coolpix S6150
2099	Nikon	Coolpix S620
3026	Nikon	Coolpix S6200
2098	Nikon	Coolpix S630
3181	Nikon	Coolpix S6300

2262	Nikon	Coolpix S640
3434	Nikon	CoolPix S6400
3411	Nikon	CoolPix S6500
3807	Nikon	Coolpix S6800
3903	Nikon	Coolpix S6900
2297	Nikon	Coolpix S70
1542	Nikon	Coolpix S700
1979	Nikon	Coolpix S710
1023	Nikon	Coolpix S7c
2633	Nikon	Coolpix S80
2446	Nikon	Coolpix S8000
2755	Nikon	Coolpix S8100
3023	Nikon	Coolpix S8200
1102	Nikon	Coolpix S9
2843	Nikon	Coolpix S9100
3182	Nikon	Coolpix S9300
3433	Nikon	CoolPix S9400
3423	Nikon	CoolPix S9500
3808	Nikon	Coolpix S9700
4024	Nikon	Coolpix S9900
622	Nikon	Coolpix SQ
4684	Nikon	COOLPIX W100
4605	Nikon	COOLPIX W300
3725	Nikon	D 5300
625	Nikon	D100
626	Nikon	D1X
619	Nikon	D200
627	Nikon	D2H
628	Nikon	D2Hs
629	Nikon	D2X
1076	Nikon	D2Xs
1543	Nikon	D3
1544	Nikon	D300
2263	Nikon	D3000
2677	Nikon	D3100
3251	Nikon	D3200/D3300/D3400
3093	Nikon	D3x / D3s
3137	Nikon	D4/D4x/D5
1114	Nikon	D40/D40x
3797	Nikon	D4s
630	Nikon	D50
3904	Nikon	D500/D750
2159	Nikon	D5000
2880	Nikon	D5100
3386	Nikon	D5200
4148	Nikon	D5300
4023	Nikon	D5500 / D5600

1698	Nikon	D60	
3311	Nikon	D600/D7100	
3665	Nikon	D610	
631	Nikon	D70	
1854	Nikon	D700	
2631	Nikon	D7000	
632	Nikon	D70s	
4025	Nikon	D7200	
4516	Nikon	D7500	
1075	Nikon	D80	
3183	Nikon	D800/D810	
4600	Nikon	D850	
1970	Nikon	D90	
3726	Nikon	DF	
4195	Nikon	DL18-50	
4196	Nikon	DL24-500	
4197	Nikon	DL24-85	
633	Nikon	F100	
4285	Nikon	KeyMission 170	
4283	Nikon	KeyMission 80	
4170	Nikon	P600/P610	
2038	Nikon	S560	
3625	Nikon	S6600	
3339	Nikon	S800c	
268	Nintendo	DS	
1152	Nintendo	DS Lite	
2214	Nintendo	Dsi	
2662	Nintendo	DSi XL	
270	Nintendo	Gameboy	
269	Nintendo	Gameboy Advance	
4358	Nintendo	Switch	
3984	Nokia		106
158	Nokia		1100
1086	Nokia	1110i	
1596	Nokia		1112
3480	Nokia		113
1634	Nokia		1200
1840	Nokia		1208
3986	Nokia		130
1622	Nokia		1600
2545	Nokia		1616
1630	Nokia		1650
2396	Nokia		1661
2002	Nokia	1680 classic	
159	Nokia		2100
4178	Nokia	215-†	
2503	Nokia		2220

3982	Nokia		225
4574	Nokia		230
1034	Nokia		2310
2526	Nokia	2323 classic	
2384	Nokia		2330
160	Nokia		2600
1937	Nokia	2600 classic	
1031	Nokia		2610
1305	Nokia		2626
1626	Nokia		2630
839	Nokia		2652
1910	Nokia	2680 slide	
2727	Nokia	2690 (nur/only Plus)	
2313	Nokia	2700 classic	
2543	Nokia	2710 Navigation	
2588	Nokia	2720 fold	
2362	Nokia	2730 classic	
1803	Nokia		2760
4367	Nokia		3
4524	Nokia	3 - CASEFIT	
3605	Nokia		301
1473	Nokia	3109/3110 classic	
32	Nokia		3120
1873	Nokia	3120 classic	
161	Nokia		3200
162	Nokia		3220
11	Nokia		3230
980	Nokia		3250
1414	Nokia		330
163	Nokia		3300
164	Nokia	3310 (2000)	
4370	Nokia	3310 (2017)	
165	Nokia		3410
1627	Nokia	3500 classic	
166	Nokia		3510
1908	Nokia	3600 slide	
167	Nokia	3650/3660	
2483	Nokia	3710 fold	
2291	Nokia	3720 classic	
4368	Nokia		5
4607	Nokia	5 - CASEFIT	
3053	Nokia		500
2018	Nokia		5000
1506	Nokia		5070
168	Nokia		5100
2171	Nokia	5130 XpressMusic	
12	Nokia	5140/5140i	

3704	Nokia		515
1178	Nokia	5200/5300	
169	Nokia		5210
1993	Nokia	5220 XpressMusic	
2570	Nokia		5228
2376	Nokia		5230
2709	Nokia		5250
1629	Nokia		5310
2332	Nokia	5310 XpressMusic	
1938	Nokia		5320
1156	Nokia		5500
2303	Nokia	5530 XpressMusic	
1631	Nokia		5610
1455	Nokia		5700
2316	Nokia	5730 XpressMusic	
2040	Nokia	5800 XpressMusic	
4369	Nokia		6
4609	Nokia	6 - CASEFIT	
3157	Nokia		600
400	Nokia		6021
29	Nokia		6030
1082	Nokia		6070
1201	Nokia		6080
1202	Nokia		6085
170	Nokia		6100
34	Nokia		6101
989	Nokia		6103
1474	Nokia	6110 Navigator	
267	Nokia		6111
1505	Nokia	6120 classic	
1944	Nokia	6124 classic	
986	Nokia		6125
990	Nokia		6131
1155	Nokia		6151
171	Nokia		6170
172	Nokia		6210
1936	Nokia	6210 Navigator	
173	Nokia		6220
1883	Nokia	6220 classic	
13	Nokia		6230
10	Nokia	6230i	
1016	Nokia		6233
1035	Nokia		6234
174	Nokia		6260
1510	Nokia		6267
836	Nokia		6270
853	Nokia		6280

1182	Nokia		6288
1311	Nokia		6290
1312	Nokia	6300/6301	
2179	Nokia	6303 classic	
175	Nokia		6310
1625	Nokia	6500 classic	
1640	Nokia	6500 slide	
176	Nokia		6510
1628	Nokia		6555
177	Nokia		6600
2023	Nokia	6600 fold	
1987	Nokia	6600 slide	
2314	Nokia	6600i slide	
178	Nokia		6610
14	Nokia		6630
179	Nokia		6650
1986	Nokia	6650 T-Mobile	
15	Nokia		6670
16	Nokia		6680
17	Nokia		6681
2199	Nokia	6700 classic	
2508	Nokia	6700 slide (nur/only Plus)	
2328	Nokia	6710 Navigator	
2343	Nokia	6720 classic	
2350	Nokia	6730 classic	
2695	Nokia	6760 slide	
180	Nokia		6800
181	Nokia		6810
182	Nokia		6820
183	Nokia		6822
4765	Nokia	7 Plus	
4766	Nokia	7 Plus - CASEFIT	
3050	Nokia		700
3048	Nokia		701
2694	Nokia		7020
184	Nokia		7200
2693	Nokia	7210 Supernova	
2496	Nokia		7230
185	Nokia		7250
186	Nokia		7260
187	Nokia		7270
188	Nokia		7280
1874	Nokia	7310 Supernova	
944	Nokia		7360
945	Nokia		7370
1313	Nokia		7373
946	Nokia		7380

1306	Nokia		7390
1509	Nokia		7500
189	Nokia		7600
190	Nokia		7610
2025	Nokia	7610 Supernova	
191	Nokia		7650
192	Nokia		7670
193	Nokia		7700
194	Nokia		7710
1645	Nokia	7900 Prism	
4606	Nokia		8
4611	Nokia	8 - CASEFIT	
3288	Nokia	808 PureView (nur/only Plus)	
195	Nokia		8210
196	Nokia		8310
1621	Nokia		8600
28	Nokia		8800
1670	Nokia	8800 Arte / Sapphire Arte	
1472	Nokia	8800 Scirocco	
197	Nokia		8850
198	Nokia		8910
199	Nokia		9210
200	Nokia		9300
201	Nokia		9500
3391	Nokia	Asha 302	
3380	Nokia	Asha 200	
3240	Nokia	Asha 201	
3262	Nokia	Asha 203	
3537	Nokia	Asha 206	
3112	Nokia	Asha 300	
3113	Nokia	Asha 303	
3349	Nokia	Asha 305 / 306	
3473	Nokia	Asha 309	
3377	Nokia	Asha 311	
3699	Nokia	Asha 501 Dual	
2913	Nokia	C1-01 (nur/only Plus)	
3099	Nokia	C2-00	
2894	Nokia	C2-01 (nur/only Plus)	
2977	Nokia	C2-02	
3114	Nokia	C2-03	
3107	Nokia	C2-05	
2604	Nokia	C3 (nur/only Plus)	
2736	Nokia	C3-01 / 01.5 Touch and Type	
2539	Nokia	C5	
2800	Nokia	C5-03	
2587	Nokia	C6	
2732	Nokia	C6-01	

2696	Nokia	C7
2664	Nokia	E5
1085	Nokia	E50
1635	Nokia	E51
2305	Nokia	E52
2933	Nokia	E6-00
854	Nokia	E60
985	Nokia	E61
1451	Nokia	E61i
2045	Nokia	E63
1446	Nokia	E65
1867	Nokia	E66
2819	Nokia	E7
992	Nokia	E70
1868	Nokia	E71
2356	Nokia	E72
2163	Nokia	E75
1456	Nokia	E90
202	Nokia	Engage QD
3624	Nokia	Lumia 1020
3793	Nokia	Lumia 1320
3706	Nokia	Lumia 1520
3912	Nokia	Lumia 2520
3565	Nokia	Lumia 510
3474	Nokia	Lumia 520
3856	Nokia	Lumia 530
3252	Nokia	Lumia 610
3403	Nokia	Lumia 620
3614	Nokia	Lumia 625 nur/only Plus
3831	Nokia	Lumia 630/635
3111	Nokia	Lumia 710
3596	Nokia	Lumia 720
3890	Nokia	Lumia 730/735
3059	Nokia	Lumia 800 (nur/only Plus)
3365	Nokia	Lumia 820
3891	Nokia	Lumia 830
3267	Nokia	Lumia 900
3366	Nokia	Lumia 920 (nur/only Plus)
3539	Nokia	Lumia 925 Fullbody nur Plus
3538	Nokia	Lumia 925 nur/only Plus
3818	Nokia	Lumia 930
203	Nokia	N-Gage
1860	Nokia	N5000
415	Nokia	N70
984	Nokia	N71
1036	Nokia	N73
1464	Nokia	N76

1939	Nokia	N78
2033	Nokia	N79
2529	Nokia	N8
991	Nokia	N80
1218	Nokia	N800
1647	Nokia	N81 8GB
2146	Nokia	N810
1668	Nokia	N82
1996	Nokia	N85
2211	Nokia	N86 8MP
3037	Nokia	N9 (nur/only Plus)
416	Nokia	N90
2371	Nokia	N900
987	Nokia	N91
1033	Nokia	N93
1463	Nokia	N93i
1331	Nokia	N95
1646	Nokia	N95 8GB
1988	Nokia	N96
2187	Nokia	N97
2348	Nokia	N97 mini
2689	Nokia	X2
2365	Nokia	X3
2733	Nokia	X3-02 Touch and Type
2387	Nokia	X6
2931	Nokia	X7
1415	Novogo	A700
1416	Novogo	C700
1417	Novogo	C900
1418	Novogo	S700
1419	Novogo	T700
1420	Novogo	T900
4342	Nubia	N1
4341	Nubia	Z11
2177	O2	Ice
152	O2	X1
1653	O2	Xda Comet
1186	O2	Xda Cosmo
1877	O2	Xda Diamond
2183	O2	Xda Diamond 2
2156	O2	Xda Guide
153	O2	Xda II
154	O2	Xda III
155	O2	Xda IIs
156	O2	Xda mini
858	O2	Xda Mini II
830	O2	Xda mini S

973	O2	Xda neo
1617	O2	Xda nova
1190	O2	Xda Orbit
1740	O2	Xda Orbit II
970	O2	Xda Phone
2031	O2	Xda Star
1815	O2	Xda terra
1133	O2	Xda Trion
3873	Odys	Neo Quad 10
634	Olympus	C-2000
635	Olympus	C-2020
636	Olympus	C-2100
637	Olympus	C-3000
638	Olympus	C-3030
639	Olympus	C-310 Zoom
640	Olympus	C-370
641	Olympus	C-4000
642	Olympus	C-460
643	Olympus	C-470
644	Olympus	C-480
648	Olympus	C-50
645	Olympus	C-5000
646	Olympus	C-5050
647	Olympus	C-5060
649	Olympus	C-60
650	Olympus	C-70
652	Olympus	C-7070
651	Olympus	C-770
653	Olympus	C-8080
4323	Olympus	DM-901
655	Olympus	E-1
656	Olympus	E-10
657	Olympus	E-20
1643	Olympus	E-3
2044	Olympus	E-30
654	Olympus	E-300
930	Olympus	E-330
1051	Olympus	E-400
1272	Olympus	E-410
1793	Olympus	E-420
2636	Olympus	E-5
567	Olympus	E-500
1273	Olympus	E-510
1834	Olympus	E-520
2512	Olympus	E-600
2086	Olympus	E-620
928	Olympus	FE-115

1081	Olympus	FE-120
926	Olympus	FE-130
927	Olympus	FE-140
1061	Olympus	FE-170
1060	Olympus	FE-180
1059	Olympus	FE-190
1904	Olympus	FE-20
1058	Olympus	FE-200
1125	Olympus	FE-210
1121	Olympus	FE-230
1122	Olympus	FE-240
1120	Olympus	FE-250
1545	Olympus	FE-280
1546	Olympus	FE-290 (X-825)
1547	Olympus	FE-300
2123	Olympus	FE-3000
2122	Olympus	FE-3010
1690	Olympus	FE-310
2061	Olympus	FE-330 (X-845)
1688	Olympus	FE-340
1689	Olympus	FE-350
1902	Olympus	FE-360
1903	Olympus	FE-370
2251	Olympus	FE-4000
2513	Olympus	FE-4030
2124	Olympus	FE-45
2253	Olympus	FE-46
2131	Olympus	FE-5000
2252	Olympus	FE-5020
2645	Olympus	FE-5030
2637	Olympus	FE-5050
663	Olympus	IR-500
1055	Olympus	mju 1000
1686	Olympus	mju 1010 / mju 1020
1691	Olympus	mju 1030
1901	Olympus	mju 1040
1898	Olympus	mju 1050 SW
1899	Olympus	mju 1060
658	Olympus	mju 400
659	Olympus	mju 410
660	Olympus	mju 500
2130	Olympus	mju 5000
2433	Olympus	mju 5010
799	Olympus	mju 600
924	Olympus	mju 700
2125	Olympus	mju 7000
2250	Olympus	mju 7010

2432	Olympus	mju 7040
925	Olympus	mju 720 SW
1054	Olympus	mju 725
1056	Olympus	mju 730
1053	Olympus	mju 740
1052	Olympus	mju 750
1119	Olympus	mju 760
1118	Olympus	mju 770 SW
1274	Olympus	mju 780
1548	Olympus	mju 790 SW
661	Olympus	mju 800
929	Olympus	mju 810
1549	Olympus	mju 820
1657	Olympus	mju 830
1687	Olympus	mju 840
1694	Olympus	mju 850
2092	Olympus	mju 9000
2126	Olympus	mju 9010
662	Olympus	mju Mini digital
827	Olympus	mju Mini digital s
2435	Olympus	mju Tough 3000
2129	Olympus	mju Tough 6000
2254	Olympus	mju Tough 6010
2431	Olympus	mju Tough 6020
2128	Olympus	mju Tough 8000
2430	Olympus	mju Tough 8010
2954	Olympus	mju Tough TG-810
3644	Olympus	OM-D E-M1 / E-M10 / E-M10 II / E-M5 II / OM-D M10 III
4340	Olympus	OM-D E-M1 II
3187	Olympus	OM-D EM5
2201	Olympus	PEN E-P1 / P2
2963	Olympus	PEN E-P3
3599	Olympus	Pen E-P5
2434	Olympus	PEN E-PL1
2761	Olympus	PEN E-PL2
3033	Olympus	Pen E-PL3
3304	Olympus	Pen E-PL5 / E-PL6
3918	Olympus	Pen E-PL7 / E-PL8
3034	Olympus	Pen E-PM1
3317	Olympus	Pen E-PM2
4171	Olympus	PEN F
3153	Olympus	SH-21
3283	Olympus	SH-25MR
823	Olympus	SP-310
953	Olympus	SP-320
824	Olympus	SP-350
825	Olympus	SP-500UZ

1057	Olympus	SP-510UZ
1124	Olympus	SP-550UZ
1693	Olympus	SP-560UZ
1900	Olympus	SP-565UZ
1695	Olympus	SP-570UZ
2127	Olympus	SP-590UZ
2428	Olympus	SP-600UZ
2756	Olympus	SP-610UZ
826	Olympus	SP-700
2429	Olympus	SP-800UZ
3031	Olympus	SP-810 UZ
3308	Olympus	SP-820UZ
3750	Olympus	Stylus 1
3571	Olympus	Stylus SH-50/SH-60
3898	Olympus	Stylus SH1/SH2
3791	Olympus	Stylus SP-100EE
3482	Olympus	Stylus SZ-16
3570	Olympus	Stylus XZ-10
3303	Olympus	Stylus XZ-2
2936	Olympus	SZ-10
3305	Olympus	SZ-14
2845	Olympus	SZ-20
2896	Olympus	SZ-30 MR
3340	Olympus	SZ-31MR
3189	Olympus	TG 620/630
3309	Olympus	TG-1 / TG-2
4336	Olympus	TG-3 / TG-4/ TG-5
2757	Olympus	TG-310
3188	Olympus	TG-320
2758	Olympus	TG-610
3032	Olympus	TG-810
3190	Olympus	TG-820 / 860
4049	Olympus	TG-850/TG-860
2759	Olympus	VG-130
3307	Olympus	VG-150
3306	Olympus	VG-160
3191	Olympus	VG-170
3192	Olympus	VH-210
2906	Olympus	VR-320/330
3193	Olympus	VR-340 / VR-360
1090	Olympus	X-790
2760	Olympus	XZ-1
2548	Orange	Boston
2795	Orange	Miami
2975	Orange	Monte Carlo
2796	Orange	San Francisco
157	Orange	SPV-M2000

2976	Orange	Stockholm
1128	Orion	NV-355
1500	Packard Bell	Compaseo 800/810SE/820/830
1421	Packard Bell	GPS 400
1422	Packard Bell	GPS 610
1871	Palm	Centro
1193	Palm	LifeDrive
2542	Palm	Pixi Plus
2349	Palm	Pre
2731	Palm	Pre 2
2889	Palm	Pre Plus (nur/only Plus)
1207	Palm	Treo
355	Palm	Treo 180
356	Palm	Treo 270
357	Palm	Treo 300
358	Palm	Treo 600
342	Palm	Treo 650
1213	Palm	Treo 680
1214	Palm	Treo 750
2140	Palm	Treo Pro
1337	Palm	Tungsten E2
1623	Palm	TX
359	Palm	Visor
360	Palm	Visor Deluxe
361	Palm	Visor Edge
362	Palm	Visor Neo
363	Palm	Visor Platinum
364	Palm	Visor Prism
365	Palm	Visor Pro
366	Palm	Visor Solo
1935	Palm	Zire 71/72
1786	Panasonic	CN-GP50
3907	Panasonic	DMC-CM1
677	Panasonic	DMC-F1-K
2411	Panasonic	DMC-FP1
2769	Panasonic	DMC-FP5
2770	Panasonic	DMC-FP7
2274	Panasonic	DMC-FP8
2416	Panasonic	DMC-FS10
2417	Panasonic	DMC-FS11
2076	Panasonic	DMC-FS15
2767	Panasonic	DMC-FS16/ FH2
2768	Panasonic	DMC-FS18 / FH5
1715	Panasonic	DMC-FS20
2074	Panasonic	DMC-FS25
1714	Panasonic	DMC-FS3 / FS5
2412	Panasonic	DMC-FS30

2414	Panasonic	DMC-FS33
2763	Panasonic	DMC-FS35 / FH25
2764	Panasonic	DMC-FS37 / FH27
3139	Panasonic	DMC-FS40 / FH6
3140	Panasonic	DMC-FS45 / FH8
3431	Panasonic	DMC-FS50
2148	Panasonic	DMC-FS6
2415	Panasonic	DMC-FS62
2077	Panasonic	DMC-FS7
2105	Panasonic	DMC-FT1 / FT2
2854	Panasonic	DMC-FT10
3194	Panasonic	DMC-FT20
2849	Panasonic	DMC-FT3
4028	Panasonic	DMC-FT30
3195	Panasonic	DMC-FT4
4478	Panasonic	DMC-FT5
903	Panasonic	DMC-FX01
1066	Panasonic	DMC-FX07
1232	Panasonic	DMC-FX10
1471	Panasonic	DMC-FX100
1276	Panasonic	DMC-FX12
1909	Panasonic	DMC-FX150
2106	Panasonic	DMC-FX150
669	Panasonic	DMC-FX2
1068	Panasonic	DMC-FX3
1297	Panasonic	DMC-FX30
1550	Panasonic	DMC-FX33
1716	Panasonic	DMC-FX35
1906	Panasonic	DMC-FX37
2079	Panasonic	DMC-FX40
800	Panasonic	DMC-FX5
1067	Panasonic	DMC-FX50
1820	Panasonic	DMC-FX500
1551	Panasonic	DMC-FX55
2073	Panasonic	DMC-FX550
2273	Panasonic	DMC-FX60
2410	Panasonic	DMC-FX66
664	Panasonic	DMC-FX7
2809	Panasonic	DMC-FX70
2591	Panasonic	DMC-FX700
2848	Panasonic	DMC-FX77
665	Panasonic	DMC-FX8
666	Panasonic	DMC-FX9
2989	Panasonic	DMC-FX90
670	Panasonic	DMC-FZ10
2579	Panasonic	DMC-FZ100
3897	Panasonic	DMC-FZ1000

2990	Panasonic	DMC-FZ150
1552	Panasonic	DMC-FZ18
674	Panasonic	DMC-FZ20
3293	Panasonic	DMC-FZ200
4284	Panasonic	DMC-FZ2000
1879	Panasonic	DMC-FZ28
671	Panasonic	DMC-FZ3
675	Panasonic	DMC-FZ30
4106	Panasonic	DMC-FZ300
2276	Panasonic	DMC-FZ35 / FZ38
672	Panasonic	DMC-FZ4
2584	Panasonic	DMC-FZ45
2988	Panasonic	DMC-FZ48
673	Panasonic	DMC-FZ5
1064	Panasonic	DMC-FZ50
3294	Panasonic	DMC-FZ62
905	Panasonic	DMC-FZ7
3643	Panasonic	DMC-FZ72
1233	Panasonic	DMC-FZ8
4399	Panasonic	DMC-FZ82 / DMC-FZ83
2722	Panasonic	DMC-G10K
1946	Panasonic	DMC-G1K / G1HD
2510	Panasonic	DMC-G2
2918	Panasonic	DMC-G3
3291	Panasonic	DMC-G5
3525	Panasonic	DMC-G6
4078	Panasonic	DMC-G70
4307	Panasonic	DMC-G81
4685	Panasonic	DMC-G9
2272	Panasonic	DMC-GF1
2762	Panasonic	DMC-GF2
2953	Panasonic	DMC-GF3
3319	Panasonic	DMC-GF5
3569	Panasonic	DMC-GF6
4029	Panasonic	DMC-GF7
2476	Panasonic	DMC-GH1
2734	Panasonic	DMC-GH2
3372	Panasonic	DMC-GH3
3896	Panasonic	DMC-GH4 / GH5 / GH5S
3142	Panasonic	DMC-GX1
3638	Panasonic	DMC-GX7
4117	Panasonic	DMC-GX8
4218	Panasonic	DMC-GX80/GX9
4362	Panasonic	DMC-GX800
1069	Panasonic	DMC-L1
1553	Panasonic	DMC-L10
667	Panasonic	DMC-LC1

668	Panasonic	DMC-LC5
676	Panasonic	DMC-LC80
3546	Panasonic	DMC-LF 1
680	Panasonic	DMC-LS1
901	Panasonic	DMC-LS3/LS2
1295	Panasonic	DMC-LS60
1275	Panasonic	DMC-LS7
1231	Panasonic	DMC-LS75
1717	Panasonic	DMC-LS80
2104	Panasonic	DMC-LS85
682	Panasonic	DMC-LX1
3908	Panasonic	DMC-LX100
4282	Panasonic	DMC-LX15
1065	Panasonic	DMC-LX2
1878	Panasonic	DMC-LX3
2671	Panasonic	DMC-LX5
3292	Panasonic	DMC-LX7
678	Panasonic	DMC-LZ1
679	Panasonic	DMC-LZ2
906	Panasonic	DMC-LZ3
902	Panasonic	DMC-LZ5
1229	Panasonic	DMC-LZ7
1713	Panasonic	DMC-LZ8 / LZ10
2765	Panasonic	DMC-S1
3138	Panasonic	DMC-S2
2766	Panasonic	DMC-S3
3141	Panasonic	DMC-SZ1
4557	Panasonic	DMC-SZ10
3426	Panasonic	DMC-SZ3
2707	Panasonic	DMC-SZ7
3425	Panasonic	DMC-SZ9
904	Panasonic	DMC-TZ1
2418	Panasonic	DMC-TZ10
2846	Panasonic	DMC-TZ18
1277	Panasonic	DMC-TZ2
2847	Panasonic	DMC-TZ22
3196	Panasonic	DMC-TZ25 / TZ31
1230	Panasonic	DMC-TZ3
3424	Panasonic	DMC-TZ36
1719	Panasonic	DMC-TZ4
3419	Panasonic	DMC-TZ41
1718	Panasonic	DMC-TZ5
3777	Panasonic	DMC-TZ56
4350	Panasonic	DMC-TZ58
2075	Panasonic	DMC-TZ6
3776	Panasonic	DMC-TZ60/61
2078	Panasonic	DMC-TZ7

4027	Panasonic	DMC-TZ71 / TZ81 / TZ101 / TZ202
2419	Panasonic	DMC-TZ8
4509	Panasonic	DMC-TZ91
3427	Panasonic	DMC-XS1
2275	Panasonic	DMC-ZX1 /Z3
141	Panasonic	EB-A102
3260	Panasonic	Eluga dL1 EB-3901
3444	Panasonic	FH10
142	Panasonic	GD55
143	Panasonic	GD87
144	Panasonic	GD97
3925	Panasonic	GM 5
3683	Panasonic	GM1
294	Panasonic	GR-D225EX
4758	Panasonic	HC-V777
3580	Panasonic	HC-X 909
3578	Panasonic	HC-X 929
4756	Panasonic	HC-X1
3345	Panasonic	HC-X900M
3577	Panasonic	HD-V727
3581	Panasonic	HDC-HS 700
1905	Panasonic	HDC-HS100
1914	Panasonic	HDC-HS9
1913	Panasonic	HDC-SD100
2195	Panasonic	HDC-SD20
2471	Panasonic	HDC-SD200
2323	Panasonic	HDC-SD300
3655	Panasonic	HDC-SD40
2501	Panasonic	HDC-SD707 EDK
1912	Panasonic	HDC-SD9
2905	Panasonic	HDC-SD99
295	Panasonic	NV-GS 1
296	Panasonic	NV-GS400EG-S
1342	Panasonic	NV-GS80
1916	Panasonic	SDR-H280
1915	Panasonic	SDR-H40
2470	Panasonic	SDR-H80
2166	Panasonic	SDR-S150
1917	Panasonic	SDR-S7
147	Panasonic	VS2
148	Panasonic	VS3
145	Panasonic	X400
149	Panasonic	X70
146	Panasonic	X800
3730	Panasonic	XS3
683	Pentax	*ist D
684	Pentax	*ist DL

867	Pentax	*ist DL2
685	Pentax	*ist DS
4033	Pentax	645Z
3233	Pentax	K-01
4192	Pentax	K-1
3667	Pentax	K-3 / K3 II
3285	Pentax	K-30 / K-50
3302	Pentax	K-5 II K-5IIs
3681	Pentax	K-500
2196	Pentax	K-7
4256	Pentax	K-70
1971	Pentax	K-m / K-x
2625	Pentax	K-r
4034	Pentax	K-S1
4035	Pentax	K-S2
1038	Pentax	K100D / K100D Super / K110
1099	Pentax	K10D
1721	Pentax	K200D
1722	Pentax	K20D
2622	Pentax	K5
4390	Pentax	KP
3437	Pentax	MX-1
686	Pentax	Optio 30
687	Pentax	Optio 33WR
688	Pentax	Optio 430RS
689	Pentax	Optio 550
690	Pentax	Optio 555
801	Pentax	Optio 60
691	Pentax	Optio 750Z
863	Pentax	Optio A10
1100	Pentax	Optio A20
1225	Pentax	Optio A30
1605	Pentax	Optio A40
865	Pentax	Optio E10
1221	Pentax	Optio E30
1607	Pentax	Optio E40
1724	Pentax	Optio E50
1976	Pentax	Optio E60
2096	Pentax	Optio E70
2218	Pentax	Optio E75
2463	Pentax	Optio E90
2459	Pentax	Optio H90
2458	Pentax	Optio I-10
3298	Pentax	Optio LS465
866	Pentax	Optio M10
1098	Pentax	Optio M20
1222	Pentax	Optio M30

1554	Pentax	Optio M40/L40
1723	Pentax	Optio M50
1975	Pentax	Optio M60
2626	Pentax	Optio M90
2462	Pentax	Optio P80
2623	Pentax	Optio RS1000
2624	Pentax	Optio RZ10
3007	Pentax	Optio RZ18
692	Pentax	Optio S
2857	Pentax	Optio S1
1555	Pentax	Optio S10
1881	Pentax	Optio S12
693	Pentax	Optio S40
694	Pentax	Optio S45
697	Pentax	Optio S4i
698	Pentax	Optio S50
695	Pentax	Optio S55
699	Pentax	Optio S5i
700	Pentax	Optio S5z
802	Pentax	Optio S6
696	Pentax	Optio S60
1073	Pentax	Optio S7
701	Pentax	Optio SV
702	Pentax	Optio Svi
864	Pentax	Optio T10/T20
1224	Pentax	Optio T30
1606	Pentax	Optio V10
1866	Pentax	Optio V20
951	Pentax	Optio W10
1097	Pentax	Optio W20
1223	Pentax	Optio W30
1977	Pentax	Optio W60
2460	Pentax	Optio W80
2461	Pentax	Optio W90
3299	Pentax	Optio WG2
704	Pentax	Optio WP
2464	Pentax	Optio WS80
703	Pentax	Optio X
2082	Pentax	Optio X70
1556	Pentax	Optio Z10
3005	Pentax	Q
3301	Pentax	Q 10
3682	Pentax	Q7/Q10
3600	Pentax	WG 3
803	Pentax	Wpi
3300	Pentax	X-5
2551	Pentax	X90

4601	Phase One XF	IQ3 100MP	
3920	Phicomm	Clue	
4048	Phicomm	Clue M	
3972	Phicomm	E 551	
3921	Phicomm	Energy M	
3737	Phicomm	FWS 610	
3454	Phicomm	FWS 650	
3455	Phicomm	FWS 710	
3456	Phicomm	i370	
3457	Phicomm	i600	
3458	Phicomm	i800	
3459	Phicomm	i813	
3944	Phicomm	Passion	
3973	Phicomm	X 100	
150	Philips		735
151	Philips		755
1148	Pioneer	AVH-P5700 DVD	
1784	Pioneer	AVIC-F500BT	
1423	Pioneer	AVIC-S1	
1424	Pioneer	AVIC-S2	
3630	Point of view	mobii 1325	
4044	Pokini	Tab A10	
4102	Pokini	Tab A8	
3463	Prestigio	MultiPhone 5000 DUO	
3688	Prestigio	MultiPhone 5300 Duo	
1846	Psion	5mx PRO	
2944	Psion	lk/¥n	
2914	Psion	PRO 3	
136	Qtek		2020
137	Qtek	2020i	
138	Qtek		8010
1172	Qtek		9000
139	Qtek		9090
968	Qtek		9100
1135	Qtek		9600
140	Qtek	S100/200	
705	Revue	DC 211	
275	Ricoh	Caplio 300G	
713	Ricoh	Caplio 400	
1483	Ricoh	Caplio 500G Wide	
714	Ricoh	Caplio G3	
715	Ricoh	Caplio G4	
804	Ricoh	Caplio GR	
1651	Ricoh	Caplio GR Digital II	
706	Ricoh	Caplio GX	
1469	Ricoh	Caplio GX100	
707	Ricoh	Caplio GX8	

708	Ricoh	Caplio R1/R1V	
709	Ricoh	Caplio R2	
805	Ricoh	Caplio R3/R4/R5	
1792	Ricoh	Caplio R50	
1296	Ricoh	Caplio R6/R7	
1791	Ricoh	Caplio R8	
710	Ricoh	Caplio RR330	
1512	Ricoh	Caplio RR750	
711	Ricoh	Caplio RZ1	
712	Ricoh	Caplio RZ2	
2329	Ricoh	CS2	
2139	Ricoh	CX1 - 6-†	
3735	Ricoh	GR	
3035	Ricoh	GR Digital IV	
4255	Ricoh	GR/GR II	
1959	Ricoh	GX200	
2859	Ricoh	GXR	
3662	Ricoh	HZ 15	
3036	Ricoh	PX	
1957	Ricoh	R10	
716	Ricoh	RDC-7	
717	Ricoh	RDC-i700	
718	Ricoh	RX	
1568	Rollei		10325
719	Rollei		3210
1566	Rollei		7325
1567	Rollei		7330
1612	Rollei		7430
1569	Rollei		8325
2915	Rollei	Compactline 360TS	
720	Rollei	dk4010	
721	Rollei	dp4200	
2739	Rollei	Flexline 250	
3640	Rollei	Movieline P5	
3816	Rollei	Powerflex 240HD	
1823	Rollei	RCP-8427XW	
1788	Rollei	RCP-S10	
1857	Rollei	X-8	
3049	Rongwei	Flytouch 3	
1425	Route 66	Chicago 6000	
1426	Route 66	Chicago 7000	
1427	Route 66	Chicago 8000	
1428	Route 66	Chicago 9000	
1582	Route 66	mini	
3837	RugGear	RG300	
3838	RugGear	RG500	
3852	RugGear	RG700	

1303	Sagem	my-400V
1316	Sagem	my-501X
1806	Sagem	my-511X
126	Sagem	my-V75
127	Sagem	my-V76
128	Sagem	my-V77
129	Sagem	my-V78
130	Sagem	my-V79
131	Sagem	my-V80
132	Sagem	my-V81
133	Sagem	my-V82
134	Sagem	my-V83
135	Sagem	my-V84
849	Sagem	my-X6?
4768	Samsung	A6
4769	Samsung	A6 - CASEFIT
4770	Samsung	A6 Plus
4771	Samsung	A6 Plus - CASEFIT
3396	Samsung	Ativ S i8750 (nur/only Plus)
2164	Samsung	B2100
2026	Samsung	B2700
2726	Samsung	B2710
2495	Samsung	B3210 TXT
2708	Samsung	B3310
2366	Samsung	B3410
2480	Samsung	B5722
2657	Samsung	B7300
2678	Samsung	B7722 Dual
2395	Samsung	Blue Earth S7550
3613	Samsung	C 3520
2315	Samsung	C3050
2317	Samsung	C3060
2653	Samsung	C3110
2818	Samsung	C3200
2605	Samsung	C3300K
3146	Samsung	C3322
2649	Samsung	C3510
3115	Samsung	C3560
3066	Samsung	C3750
2680	Samsung	C6625
2952	Samsung	Ch@t322 C3222
2948	Samsung	Ch@t335 S3350
2870	Samsung	Ch@t350 C3500
3148	Samsung	Champ 2 C3330
3379	Samsung	Champ Deluxe C3310
2904	Samsung	Champ DuoS E2652
3044	Samsung	Champ S3770

2540	Samsung	Corby 3G S3370
2912	Samsung	Corby II S3850
2530	Samsung	Corby Pro B5310
2322	Samsung	Corby S3650
2141	Samsung	D980 DuoS
722	Samsung	DIGIMAX A400
723	Samsung	DIGIMAX A402
724	Samsung	DIGIMAX A5
1006	Samsung	DIGIMAX A50
872	Samsung	DIGIMAX A503
725	Samsung	DIGIMAX A6
732	Samsung	DIGIMAX i5
807	Samsung	DIGIMAX i50
868	Samsung	DIGIMAX i6/NV3/NV10
819	Samsung	DIGIMAX L55w
873	Samsung	DIGIMAX L60
874	Samsung	DIGIMAX L85
733	Samsung	DIGIMAX Pro 815
871	Samsung	DIGIMAX S500
869	Samsung	DIGIMAX S600
870	Samsung	DIGIMAX S800
730	Samsung	DIGIMAX U-CA 5
726	Samsung	DIGIMAX V4
727	Samsung	DIGIMAX V5
728	Samsung	DIGIMAX V50 V70
729	Samsung	DIGIMAX V6
731	Samsung	DIGIMAX V700
818	Samsung	DIGIMAX V800
2386	Samsung	DuoS B5702-†
2180	Samsung	DuoS C5212
2472	Samsung	DuoS C6112 (nur/only Plus)
3197	Samsung	DV300F
2491	Samsung	E1070
2652	Samsung	E1120
2922	Samsung	E1130
2930	Samsung	E2152
2650	Samsung	E2370
2134	Samsung	ES55
2455	Samsung	ES70
2597	Samsung	ES75
2951	Samsung	ES80
2449	Samsung	EX1
3338	Samsung	EX2F
2556	Samsung	Galaxy 3 i5800
2651	Samsung	Galaxy 550 i5500
3933	Samsung	Galaxy A3 (2015)
4154	Samsung	Galaxy A3 (2016)

4320	Samsung	Galaxy A3 (2017)
4391	Samsung	Galaxy A3 (2017) - CASEFIT
3934	Samsung	Galaxy A5 (2015)
4155	Samsung	Galaxy A5 (2016)
4321	Samsung	Galaxy A5 (2017)
4392	Samsung	Galaxy A5 (2017) - CASEFIT
3935	Samsung	Galaxy A7
4677	Samsung	Galaxy A8
4678	Samsung	Galaxy A8 - CASEFIT
4704	Samsung	Galaxy A8 Plus
4705	Samsung	Galaxy A8 Plus - CASEFIT
3255	Samsung	Galaxy Ace 2 i8160
3631	Samsung	Galaxy Ace 3-†
3953	Samsung	Galaxy Ace 4
3287	Samsung	Galaxy Ace DuoS S6802
3164	Samsung	Galaxy Ace Plus S7500
2815	Samsung	Galaxy Ace S5830
3851	Samsung	Galaxy Ace Style
3879	Samsung	Galaxy Alpha
3272	Samsung	Galaxy Beam i8530
4378	Samsung	Galaxy Book 10.6
3318	Samsung	Galaxy Camera
3814	Samsung	Galaxy Camera 2
3651	Samsung	Galaxy Core / Core DouS
3923	Samsung	Galaxy Core 2
3773	Samsung	Galaxy Core 4G
3657	Samsung	Galaxy Core Plus
4114	Samsung	Galaxy Core Prime
3749	Samsung	Galaxy Express 2
3597	Samsung	Galaxy Express i8730
3470	Samsung	Galaxy Fame GT-S6810P
2937	Samsung	Galaxy Fit S5670 (nur/only Plus)
3967	Samsung	Galaxy Gear 2 Neo
3970	Samsung	Galaxy Gear S-†
3718	Samsung	Galaxy Grand / Grand Neo / Neo +
4018	Samsung	Galaxy Grand Prime
2312	Samsung	Galaxy i7500
4051	Samsung	Galaxy J1
4223	Samsung	Galaxy J1 (2016)
4187	Samsung	Galaxy J3 (2016)
4542	Samsung	Galaxy J3 (2017)
4543	Samsung	Galaxy J3 (2017) - CASEFIT
4081	Samsung	Galaxy J5 (2015)
4287	Samsung	Galaxy J5 (2016)
4518	Samsung	Galaxy J5 (2017)
4519	Samsung	Galaxy J5 (2017) - CASEFIT
4526	Samsung	Galaxy J7 (2017)

4527	Samsung	Galaxy J7 (2017) - CASEFIT
3865	Samsung	Galaxy K Zoom
2557	Samsung	Galaxy Leo i5801
3510	Samsung	Galaxy mega 6.3 I9200
3492	Samsung	Galaxy mega 6.3, Fullbody Plus
3162	Samsung	Galaxy mini 2 S6500
2820	Samsung	Galaxy mini S5570-†
3072	Samsung	Galaxy nexus prime i9250 (nur/only Plus)
3324	Samsung	Galaxy Note 10.1 N8000
3296	Samsung	Galaxy Note 2 N7100 nur/only Plus-†
3626	Samsung	Galaxy Note 3
3771	Samsung	Galaxy Note 3 Neo
3889	Samsung	Galaxy Note 4
4230	Samsung	Galaxy Note 7
4544	Samsung	Galaxy Note 8
4545	Samsung	Galaxy Note 8 - CASEFIT
3542	Samsung	Galaxy Note 8.0 N5100
3966	Samsung	Galaxy Note Edge
3051	Samsung	Galaxy Note N7000
3637	Samsung	Galaxy NX
3676	Samsung	Galaxy Pocket Neo S5310
3249	Samsung	Galaxy Pocket S5300
3658	Samsung	Galaxy Pocket S5301
2946	Samsung	Galaxy Pro B7510-†
3081	Samsung	Galaxy R i9103
2884	Samsung	Galaxy S (SCL) i9003
3243	Samsung	Galaxy S Advance i9070 (nur/only Plus)
4019	Samsung	Galaxy S DuoS 2 S7582
3327	Samsung	Galaxy S DuoS S7562
2812	Samsung	Galaxy S G. Armani i9010
2518	Samsung	Galaxy S i9000
2945	Samsung	Galaxy S Plus i9001
3149	Samsung	Galaxy S Wifi 3.6 YP-GS1
3282	Samsung	Galaxy S YP-G70 Wifi 5.0
3489	Samsung	Galaxy S2, Fullbody Plus
2890	Samsung	Galaxy S2/S2 Plus i9100/i9105
3353	Samsung	Galaxy S3 Mini i8190
3491	Samsung	Galaxy S3 mini, Fullbody nur Plus
3490	Samsung	Galaxy S3, Fullbody nur Plus
3242	Samsung	Galaxy S3/ S3 neo
3412	Samsung	Galaxy S4 i9500/ i9505
3559	Samsung	Galaxy S4 Active I9295
3516	Samsung	Galaxy S4 mini
3519	Samsung	Galaxy S4 mini Fullbody Plus
3641	Samsung	Galaxy S4 Zoom
3488	Samsung	Galaxy S4, Fullbody Plus
3765	Samsung	Galaxy S5 / S5 neo

3962	Samsung	Galaxy S5 Active
3836	Samsung	Galaxy S5 Mini
3997	Samsung	Galaxy S6
4017	Samsung	Galaxy S6 Edge
4555	Samsung	Galaxy S6 Edge - CASEFIT
4082	Samsung	Galaxy S6 Edge Plus
4164	Samsung	Galaxy S7
4455	Samsung	Galaxy S7 - CASEFIT
4165	Samsung	Galaxy S7 Edge
4457	Samsung	Galaxy S7 Edge - CASEFIT
4365	Samsung	Galaxy S8
4334	Samsung	Galaxy S8 - CASEFIT
4366	Samsung	Galaxy S8 Plus
4335	Samsung	Galaxy S8 Plus - CASEFIT
4689	Samsung	Galaxy S9†
4690	Samsung	Galaxy S9 - CASEFIT
4692	Samsung	Galaxy S9 Plus
4693	Samsung	Galaxy S9 Plus - CASEFIT
2385	Samsung	Galaxy Spica i5700
3700	Samsung	Galaxy Star S5280
2648	Samsung	Galaxy Tab
3079	Samsung	Galaxy Tab 10.1N P7501†
3250	Samsung	Galaxy Tab 2 10.1 P5110
3271	Samsung	Galaxy Tab 2 7.0 P3100
3521	Samsung	Galaxy Tab 3 10.1
3495	Samsung	Galaxy Tab 3 10.1 Zoll Fullbody
3493	Samsung	Galaxy Tab 3 7 Zoll Fullbody nur Plus
3520	Samsung	Galaxy Tab 3 7.0
3561	Samsung	Galaxy Tab 3 8 Zoll
3494	Samsung	Galaxy Tab 3 8 Zoll, Fullbody
3846	Samsung	Galaxy Tab 4 10.1"
3844	Samsung	Galaxy Tab 4 7"
3845	Samsung	Galaxy Tab 4 8"
3151	Samsung	Galaxy Tab 7.7 P6800
3110	Samsung	Galaxy Tab 8.9 P7300
4298	Samsung	Galaxy Tab A (2016) 10,1"
4326	Samsung	Galaxy Tab A (2016) 7" LTE (T285)
4325	Samsung	Galaxy Tab A (2016) 7" WIFI (T280)
4076	Samsung	Galaxy Tab A 9,7"
4650	Samsung	Galaxy Tab Active 2
4118	Samsung	Galaxy Tab S2 9.7
4140	Samsung	Galaxy Tab S2 8.0 LTE
4224	Samsung	Galaxy Tab S2 8.0 WIFI
4377	Samsung	Galaxy Tab S3
3040	Samsung	Galaxy Tab10.1 P7100
2955	Samsung	Galaxy Tab10.1 P7500
4206	Samsung	Galaxy TabPro S

3922	Samsung	Galaxy Trend 2
3710	Samsung	Galaxy Trend lite
3774	Samsung	Galaxy Trend Plus
3687	Samsung	Galaxy Trend S7560
3043	Samsung	Galaxy W i8150
3100	Samsung	Galaxy Wave 3 S8600
3222	Samsung	Galaxy Xcover 2 C3350
3447	Samsung	Galaxy Xcover 2 S7710
4066	Samsung	Galaxy Xcover 3
4429	Samsung	Galaxy XCover 4
3087	Samsung	Galaxy Xcover S5690
3090	Samsung	Galaxy Y (O2) S5363
3550	Samsung	Galaxy y Duos GT-S6312
3217	Samsung	Galaxy Y DuoS S6102
3082	Samsung	Galaxy Y Pro B5510-†
3054	Samsung	Galaxy Y S5360
3968	Samsung	Galaxy young 2
3549	Samsung	Galaxy Young S6310 N
3872	Samsung	Gear Fit
4314	Samsung	Gear Fit 2
4602	Samsung	Gear Fit 2 Pro
4578	Samsung	Gear S2
4579	Samsung	Gear S3
4620	Samsung	Gear Sport
2888	Samsung	Gio S5660
2473	Samsung	Giogio Armani B7620
1302	Samsung	GX10
875	Samsung	GX1L
876	Samsung	GX1S
1682	Samsung	GX20
2338	Samsung	H1 Vodafone 360
2204	Samsung	HD i8910
2938	Samsung	HMX-H300
3671	Samsung	HMX-H400
2072	Samsung	HZ10W
2069	Samsung	HZ15W
1925	Samsung	i100
2655	Samsung	i5510
1280	Samsung	i7
1279	Samsung	i70
1680	Samsung	i8
1557	Samsung	i85
2198	Samsung	J?t S8000
1679	Samsung	L110/L210
1983	Samsung	L200
1923	Samsung	L201
1922	Samsung	L310 W

1290	Samsung	L70
1070	Samsung	L70
1281	Samsung	L700
1282	Samsung	L73
1608	Samsung	L730
1289	Samsung	L74
1288	Samsung	L77
1558	Samsung	L830
1559	Samsung	L83T
2342	Samsung	M1 Vodafone 360
2165	Samsung	M3510 Beat b
2582	Samsung	M5650
2336	Samsung	M7600 BEAT DJ
2487	Samsung	Monte S5620
2886	Samsung	Monte Slide E2550
2996	Samsung	MV800
3321	Samsung	MV900F
2803	Samsung	Nexus S (nur/only Plus)
3741	Samsung	Note 10.1 2014 Edition
1093	Samsung	NV10
1972	Samsung	NV100 HD
1287	Samsung	NV11
1560	Samsung	NV15
1561	Samsung	NV20
1678	Samsung	NV24 HD
1094	Samsung	NV3
1677	Samsung	NV30
1681	Samsung	NV4
1074	Samsung	NV7 OPS
1562	Samsung	NV8
1924	Samsung	NV9
3909	Samsung	NX 1
3284	Samsung	NX 20
3322	Samsung	NX 210 / NX1000
3815	Samsung	NX 30
3895	Samsung	NX 3000/NX3300
3834	Samsung	NX mini
2640	Samsung	NX100
2778	Samsung	NX11
2995	Samsung	NX200
3618	Samsung	NX2000
3439	Samsung	NX300
2450	Samsung	NX5 / NX10
4059	Samsung	NX500
2710	Samsung	OMNIA 7
3159	Samsung	OMNIA 735
2330	Samsung	Omnia II i8000

2586	Samsung	Omnia Pro B7330-†
3070	Samsung	Omnia W i8350
2311	Samsung	OmniaPro B7610
2853	Samsung	OmniPro4 B7350-†
2200	Samsung	Pilot i7110
2325	Samsung	Pixon12 M8910-†
2456	Samsung	PL100
2771	Samsung	PL120
2454	Samsung	PL150
2772	Samsung	PL170
2647	Samsung	PL200
2596	Samsung	PL200
2775	Samsung	PL210
2300	Samsung	PL50
2299	Samsung	PL51
2132	Samsung	PL60
2133	Samsung	PL65
2457	Samsung	PL80
2595	Samsung	PL90
3008	Samsung	RV720
3674	Samsung	S 3800 Rex 70
1071	Samsung	S1000
1283	Samsung	S1050
2035	Samsung	S1060
2679	Samsung	S3100
2656	Samsung	S3350
2547	Samsung	S3550
3039	Samsung	S3550i
2367	Samsung	S5200
2173	Samsung	S5230
2659	Samsung	S5250
2549	Samsung	S5550
2372	Samsung	S5560
2307	Samsung	S5600
3261	Samsung	S5610/S5611
1284	Samsung	S630
1096	Samsung	S700
2398	Samsung	S7070
1285	Samsung	S730
1609	Samsung	S750
2337	Samsung	S8300V
1286	Samsung	S850
4379	Samsung	Samsung Galaxy Book 12
38	Samsung	SGH-A800
39	Samsung	SGH-C100
1821	Samsung	SGH-C200N
286	Samsung	SGH-C210

1588	Samsung	SGH-C300
939	Samsung	SGH-D200
40	Samsung	SGH-D410
18	Samsung	SGH-D500
996	Samsung	SGH-D520
23	Samsung	SGH-D600
938	Samsung	SGH-D800
977	Samsung	SGH-D820
1211	Samsung	SGH-D830
1340	Samsung	SGH-D840
1744	Samsung	SGH-D880
1091	Samsung	SGH-D900
1448	Samsung	SGH-D900i
1669	Samsung	SGH-E200
1210	Samsung	SGH-E250
41	Samsung	SGH-E310
42	Samsung	SGH-E330
43	Samsung	SGH-E340
44	Samsung	SGH-E348
1020	Samsung	SGH-E370
1092	Samsung	SGH-E380
1179	Samsung	SGH-E500
45	Samsung	SGH-E530
1940	Samsung	SGH-E570
1591	Samsung	SGH-E590
46	Samsung	SGH-E600
47	Samsung	SGH-E620
48	Samsung	SGH-E630
49	Samsung	SGH-E700
50	Samsung	SGH-E710
24	Samsung	SGH-E730
1590	Samsung	SGH-E740
937	Samsung	SGH-E760
1158	Samsung	SGH-E770
19	Samsung	SGH-E800
51	Samsung	SGH-E810
52	Samsung	SGH-E820
1459	Samsung	SGH-E840
53	Samsung	SGH-E850
21	Samsung	SGH-E860V
1017	Samsung	SGH-E900
1747	Samsung	SGH-E950
1941	Samsung	SGH-F110 adidas
1589	Samsung	SGH-F300
2192	Samsung	SGH-F400
1852	Samsung	SGH-F480 / V / i
1807	Samsung	SGH-F490

1663	Samsung	SGH-F700 QBowl
1875	Samsung	SGH-F700 QBowl Vodafone
1633	Samsung	SGH-G600
1658	Samsung	SGH-G800
1853	Samsung	SGH-G810
855	Samsung	SGH-i300
1811	Samsung	SGH-i550
2014	Samsung	SGH-i560
1468	Samsung	SGH-i600
1809	Samsung	SGH-i620
1664	Samsung	SGH-i750
1942	Samsung	SGH-i780
1992	Samsung	SGH-i8510 innov8
1870	Samsung	SGH-i900 Omnia
2091	Samsung	SGH-J150
1790	Samsung	SGH-J600
1810	Samsung	SGH-J700
1995	Samsung	SGH-L700
1641	Samsung	SGH-L760
1945	Samsung	SGH-L810 V
1741	Samsung	SGH-M110
2185	Samsung	SGH-M200
1586	Samsung	SGH-M300
2030	Samsung	SGH-M8800 Pixon
54	Samsung	SGH-N500
994	Samsung	SGH-P300
1191	Samsung	SGH-P310
55	Samsung	SGH-P400
56	Samsung	SGH-P510
1666	Samsung	SGH-P520 Giorgio Armani
57	Samsung	SGH-P730
1176	Samsung	SGH-P900
58	Samsung	SGH-S300
59	Samsung	SGH-S342i
2151	Samsung	SGH-S3500
2170	Samsung	SGH-S3600
60	Samsung	SGH-S500
61	Samsung	SGH-T100
2197	Samsung	SGH-U100
1332	Samsung	SGH-U600
1457	Samsung	SGH-U700
1848	Samsung	SGH-U800
1812	Samsung	SGH-U900
62	Samsung	SGH-V200
280	Samsung	SGH-V800
63	Samsung	SGH-X100
851	Samsung	SGH-X200

64	Samsung	SGH-X450
65	Samsung	SGH-X460
66	Samsung	SGH-X480
1157	Samsung	SGH-X500
1180	Samsung	SGH-X510
1315	Samsung	SGH-X530
67	Samsung	SGH-X600
36	Samsung	SGH-X640
808	Samsung	SGH-X660
68	Samsung	SGH-X670
850	Samsung	SGH-X700
837	Samsung	SGH-X800
1026	Samsung	SGH-X820
1184	Samsung	SGH-X830
281	Samsung	SGH-X880
69	Samsung	SGH-Z105
70	Samsung	SGH-Z107
71	Samsung	SGH-Z110
1005	Samsung	SGH-Z140
1309	Samsung	SGH-Z150
1079	Samsung	SGH-Z400
72	Samsung	SGH-Z500
995	Samsung	SGH-Z510
1447	Samsung	SGH-Z630
828	Samsung	SGH-ZV10
806	Samsung	SGH-ZV30
2774	Samsung	SH100
2728	Samsung	Shark S5350
3628	Samsung	Smartwatch Galaxy Gear
2593	Samsung	ST100
2285	Samsung	ST1000
3198	Samsung	ST200
2515	Samsung	ST45
2135	Samsung	ST50
2301	Samsung	ST500
2452	Samsung	ST5000
2302	Samsung	ST550
2453	Samsung	ST60
2594	Samsung	ST600
3199	Samsung	ST66 / ST77
2516	Samsung	ST70
2773	Samsung	ST700
2592	Samsung	ST80
3200	Samsung	ST88
2997	Samsung	ST93
3244	Samsung	Star 3 S5220
2828	Samsung	Star II S5260†

2949	Samsung	Star2 DuoS C6712
2087	Samsung	TL320
2145	Samsung	Ultra Touch S8300
2216	Samsung	UltraClassic S7220
2176	Samsung	UltraS S7350-†
2326	Samsung	V Blade S5600
2654	Samsung	Wave 533 S5330-†
2658	Samsung	Wave 723 S7230
2729	Samsung	Wave II S8530
3068	Samsung	Wave M S7250
2519	Samsung	Wave S8500 (nur/only Plus)
3069	Samsung	Wave Y S5380-†
3812	Samsung	WB 1100F
3813	Samsung	WB 2200F
3811	Samsung	WB 35F
3810	Samsung	WB 50F
2136	Samsung	WB100 Modell 2009
3398	Samsung	WB100 Modell 2012
2353	Samsung	WB1000
3201	Samsung	WB150F
2639	Samsung	WB2000
2776	Samsung	WB210
3441	Samsung	WB250F/350F/380F
2137	Samsung	WB500 / 510
2517	Samsung	WB5000 / 5500
2138	Samsung	WB550 / 560
2451	Samsung	WB600 /WB650
2777	Samsung	WB700
2998	Samsung	WB750
3440	Samsung	WB800F
3202	Samsung	WB850
4115	Samsung	Xcover 550
1595	Samsung	YP-K3
2399	Samsung	YP-M1
2486	Samsung	YP-Q1
2499	Samsung	YP-S3 (nur/only Plus)
2153	Sanyo	VPC-E10
2638	Sanyo	VPC-E1403
1187	Sanyo	VPC-E7
1188	Sanyo	VPC-S7
734	Sanyo	Xacti C4
735	Sanyo	Xacti C5
809	Sanyo	Xacti E6
959	Sanyo	Xacti S60
1662	Sanyo	Xacti S70
740	Sanyo	Xacti VPC-C5
1829	Sanyo	Xacti VPC-CG65

2013	Sanyo	Xacti VPC-HD1010
737	Sanyo	Xacti VPC-J4 EX
738	Sanyo	Xacti VPC-S1
739	Sanyo	Xacti VPC-S4
736	Sanyo	Xacti VPC-S5
2646	Sanyo	Xcati-VPC1200/1220
1013	SEG	PHP 5600
73	Sendo	Sendo SV663
74	Sendo	Sendo X
3092	Sharp	Aquos Phone SH80F
75	Sharp	GX10i
78	Sharp	GX15
79	Sharp	GX20
76	Sharp	GX25
77	Sharp	GX30
80	Sharp	TM100
81	Sharp	TM200
82	Sharp	V902
1028	Siemens	A31
83	Siemens	A50
84	Siemens	A57
85	Siemens	A60
86	Siemens	A62
87	Siemens	A65
88	Siemens	A70
840	Siemens	A75
1087	Siemens	AX72
89	Siemens	C35
90	Siemens	C55
91	Siemens	C60
92	Siemens	C62
93	Siemens	C65
406	Siemens	C75
403	Siemens	CF110
94	Siemens	CF62
95	Siemens	CFX65
96	Siemens	CI50
402	Siemens	CL75
97	Siemens	CV65
98	Siemens	CX65
99	Siemens	CX70
33	Siemens	CX75
100	Siemens	CXT70
2536	Siemens	Gigaset SL3H
2209	Siemens	Gigaset SL785
3218	Siemens	Gigaset SL910
101	Siemens	M50

102	Siemens	M55
31	Siemens	M65
35	Siemens	M75
103	Siemens	MC60
104	Siemens	ME45
842	Siemens	ME75
105	Siemens	MT50
106	Siemens	S35
107	Siemens	S45
108	Siemens	S55
20	Siemens	S65
841	Siemens	S75
109	Siemens	SF65
852	Siemens	SGX75
110	Siemens	SL42i
111	Siemens	SL45i
112	Siemens	SL55
22	Siemens	SL65
834	Siemens	SL75
297	Siemens	SP65
113	Siemens	ST55
114	Siemens	ST60
115	Siemens	SX1
116	Siemens	SX45
117	Siemens	U10
118	Siemens	U15
119	Siemens	Xelibri 1
120	Siemens	Xelibri 2
121	Siemens	Xelibri 3
122	Siemens	Xelibri 5
123	Siemens	Xelibri 6
124	Siemens	Xelibri 7
125	Siemens	Xelibri 8
1291	Sigma	DP1
812	Sigma	SD10
1292	Sigma	SD14
2576	Sigma	SD15
741	Sigma	SD9
3501	Simvalley	Mobile SPX-8, Dual-SIM-Smarthone
3529	Simvalley	SP-120
3375	Simvalley	SP-140
4322	Smok	G-Priv 220 Mod
1855	Sonim	XP1
2685	Sonim	XP2 10 Spirit
2147	Sonim	XP3 Enduro
3230	Sonim	XP5300 FORCE 3G
3143	Sony	NEX-7

2318	Sony	Aino
3666	Sony	Alpha 3000
3789	Sony	Alpha 5000/5100
3790	Sony	Alpha 6000/6300/6500
4172	Sony	Alpha 68
3724	Sony	Alpha 7 / 7R / 7S
3993	Sony	Alpha 7 II / 7R II / 9 / 7R III-†
3002	Sony	Alpha 77 / Alpha 77 II
2094	Sony	C510
1835	Sony	C702
2217	Sony	C901 GreenHeart
1838	Sony	C902
2287	Sony	C903
1997	Sony	C905
298	Sony	CCD-TRV418
1123	Sony	Cliv© NX70V/NX60
27	Sony	D750i
299	Sony	DCR-HC30
300	Sony	DCR-HC85
742	Sony	DCR-P101
301	Sony	DCR-PC110E
2059	Sony	DCR-SR210E
2213	Sony	DCR-SR37
2149	Sony	DCR-SX30E
743	Sony	DCR-TRV 50
305	Sony	DCR-TRV17E
306	Sony	DCR-TRV30E
302	Sony	DCR-TRV30E
303	Sony	DCR-TRV355E
304	Sony	DCR-TRV480
786	Sony	DSC - P10
3620	Sony	DSC TX30
745	Sony	DSC-F505
746	Sony	DSC-F707
747	Sony	DSC-F717
748	Sony	DSC-F828
749	Sony	DSC-F88
1240	Sony	DSC-G1
750	Sony	DSC-H1
1705	Sony	DSC-H10
949	Sony	DSC-H2
2286	Sony	DSC-H20
3443	Sony	DSC-H200
1563	Sony	DSC-H3
3787	Sony	DSC-H400
1004	Sony	DSC-H5
1796	Sony	DSC-H50

2442	Sony	DSC-H55
1243	Sony	DSC-H7
2782	Sony	DSC-H70
1242	Sony	DSC-H9
3203	Sony	DSC-H90
2116	Sony	DSC-HX1
2901	Sony	DSC-HX100V
3238	Sony	DSC-HX10V
3204	Sony	DSC-HX200
3205	Sony	DSC-HX20V
3483	Sony	DSC-HX300
4388	Sony	DSC-HX350
3786	Sony	DSC-HX400V
3524	Sony	DSC-HX50/HX50V
2437	Sony	DSC-HX5VN
3788	Sony	DSC-HX60/HX60V
2779	Sony	DSC-HX7V
4077	Sony	DSC-HX90V / HX80
2898	Sony	DSC-HX9V
751	Sony	DSC-L1
983	Sony	DSC-M2
820	Sony	DSC-N1
1110	Sony	DSC-N2
752	Sony	DSC-P1
760	Sony	DSC-P10
753	Sony	DSC-P100
761	Sony	DSC-P12
754	Sony	DSC-P120
755	Sony	DSC-P200
756	Sony	DSC-P41
762	Sony	DSC-P50
757	Sony	DSC-P5CAN
763	Sony	DSC-P73
758	Sony	DSC-P8
759	Sony	DSC-P9
764	Sony	DSC-P93
821	Sony	DSC-R1
3390	Sony	DSC-RX1 / RX1R
3723	Sony	DSC-RX10/ RX 10 II / RX 10 III / RX 10 IV
3276	Sony	DSC-RX100
3619	Sony	DSC-RX100 II / III / IV / V
3619	Sony	DSC-HX95/ HX99
4143	Sony	DSC-RX1R II
2603	Sony	DSC-S210
2439	Sony	DSC-S2100
1037	Sony	DSC-S500
765	Sony	DSC-S60

881	Sony	DSC-S600
1227	Sony	DSC-S650
766	Sony	DSC-S70
1293	Sony	DSC-S700
1704	Sony	DSC-S730
1706	Sony	DSC-S750 / S780
767	Sony	DSC-S80
2190	Sony	DSC-S800
744	Sony	DSC-S85
768	Sony	DSC-S90
2117	Sony	DSC-S930
2118	Sony	DSC-S950
769	Sony	DSC-T1
1072	Sony	DSC-T10
1244	Sony	DSC-T100
2784	Sony	DSC-T110
1659	Sony	DSC-T2
1239	Sony	DSC-T20
1564	Sony	DSC-T200
770	Sony	DSC-T3
982	Sony	DSC-T30
1703	Sony	DSC-T300
771	Sony	DSC-T33
822	Sony	DSC-T5
1111	Sony	DSC-T50
1918	Sony	DSC-T500
772	Sony	DSC-T7
1565	Sony	DSC-T70
1919	Sony	DSC-T700
1921	Sony	DSC-T77
862	Sony	DSC-T9
2085	Sony	DSC-T90
2084	Sony	DSC-T900
2674	Sony	DSC-T99
3429	Sony	DSC-TF1
2266	Sony	DSC-TX1
2783	Sony	DSC-TX10
2781	Sony	DSC-TX100V
3206	Sony	DSC-TX20
2443	Sony	DSC-TX5
3121	Sony	DSC-TX55
2389	Sony	DSC-TX7
2601	Sony	DSC-TX9
773	Sony	DSC-U30
774	Sony	DSC-V1
775	Sony	DSC-V3
3646	Sony	DSC-W 730

776	Sony	DSC-W1
810	Sony	DSC-W10
877	Sony	DSC-W100
1920	Sony	DSC-W110 / W115
811	Sony	DSC-W12
1707	Sony	DSC-W120 / W130
780	Sony	DSC-W15
1708	Sony	DSC-W150 / W170
778	Sony	DSC-W17
2268	Sony	DSC-W180
1241	Sony	DSC-W200
2115	Sony	DSC-W210 / W220
2359	Sony	DSC-W215
2358	Sony	DSC-W230
2162	Sony	DSC-W270
2114	Sony	DSC-W290
880	Sony	DSC-W30
1849	Sony	DSC-W300
2568	Sony	DSC-W310
2441	Sony	DSC-W320 / W350
2641	Sony	DSC-W330
1228	Sony	DSC-W35
2440	Sony	DSC-W360
2438	Sony	DSC-W380
2642	Sony	DSC-W390
950	Sony	DSC-W40
779	Sony	DSC-W5
879	Sony	DSC-W50
2789	Sony	DSC-W510
2788	Sony	DSC-W530
1226	Sony	DSC-W55
2787	Sony	DSC-W560 / W550
2786	Sony	DSC-W570
3118	Sony	DSC-W610
3119	Sony	DSC-W620
3120	Sony	DSC-W650
3207	Sony	DSC-W690
777	Sony	DSC-W7
878	Sony	DSC-W70
1245	Sony	DSC-W80/W85/W90
3445	Sony	DSC-WX 150
3515	Sony	DSC-WX 60/ WX 80
2267	Sony	DSC-WX1
2785	Sony	DSC-WX10
3544	Sony	DSC-WX200 / 220
3098	Sony	DSC-WX30
3507	Sony	DSC-WX300

3785	Sony	DSC-WX350
2602	Sony	DSC-WX5
3208	Sony	DSC-WX50 / WX100
4141	Sony	DSC-WX500
2856	Sony	DSC-WX7
2780	Sony	DSC-WX9
1022	Sony	DSLR-Alpha 100
1711	Sony	DSLR-Alpha 200
2202	Sony	DSLR-Alpha 230
2599	Sony	DSLR-Alpha 290
1712	Sony	DSLR-Alpha 300
2598	Sony	DSLR-Alpha 33/55
2378	Sony	DSLR-Alpha 330
2999	Sony	DSLR-Alpha 35
1710	Sony	DSLR-Alpha 350
2203	Sony	DSLR-Alpha 380
2875	Sony	DSLR-Alpha 390
2475	Sony	DSLR-Alpha 450
2270	Sony	DSLR-Alpha 500
2271	Sony	DSLR-Alpha 550
2600	Sony	DSLR-Alpha 560/580
3001	Sony	DSLR-Alpha 65V / 57
1610	Sony	DSLR-Alpha 700
2269	Sony	DSLR-Alpha 850
1947	Sony	DSLR-Alpha 900
2484	Sony	F100i Jalou
2027	Sony	F305
4778	Sony	FDR-AX 33
2028	Sony	G502
1837	Sony	G700
2032	Sony	G705
1828	Sony	G900
2467	Sony	HDR-AX2000E
2490	Sony	HDR-CX115
3108	Sony	HDR-CX130
2687	Sony	HDR-CX350VE
4671	Sony	HDR-CX625
2964	Sony	HDR-CX700VE
3226	Sony	HDR-CX730
307	Sony	HDR-HC1
2011	Sony	HDR-HC9E
3632	Sony	HDR-PJ780VE
1819	Sony	HDR-SR11E / 12E
3241	Sony	HDR-TD10E
3722	Sony	HDR-TD30VE
2095	Sony	HDR-TG1E / TG3E
2489	Sony	HDR-TG7

2670	Sony	HDR-XR155E
3239	Sony	HDR-XR160
2357	Sony	HDR-XR520VE
2730	Sony	HDR-XR550VEB
2507	Sony	J102i Elm
2610	Sony	J108i Cedar
2413	Sony	J20i Hazel
1508	Sony	J220i
1467	Sony	K200i/K220i
1077	Sony	K300i
1199	Sony	K310i
1785	Sony	K320i
1161	Sony	K510i
1592	Sony	K530i
1089	Sony	K550i
408	Sony	K600i
1024	Sony	K610i
1813	Sony	K660i
4	Sony	K750i
1638	Sony	K770i
1015	Sony	K800i
1338	Sony	K810i
1618	Sony	K850i
1138	Sony	KAF65
4718	Sony	L2
4719	Sony	L2 - CASEFIT
2608	Sony	M1i Aspen
1019	Sony	M600i
781	Sony	Mavica MVC-CD 300
782	Sony	Mavica MVC-CD 400
783	Sony	Mavica MVC-CD 500
2790	Sony	MHS-FS3
2969	Sony	Mix Walkman
784	Sony	MVC-CD500
785	Sony	MVC-FD83
2393	Sony	Naite
3477	Sony	NEX 3 N +18-55
2522	Sony	NEX-3 / NEX-5
3371	Sony	NEX-5R
3680	Sony	NEX-5T
3332	Sony	NEX-6
3000	Sony	NEX-C3 / NEX-5N†
3320	Sony	NEX-F3
1127	Sony	NV-U50/70
1429	Sony	NV-U51
1571	Sony	NV-U52D
1011	Sony	NV-U70T

1430	Sony	NV-U71T
1572	Sony	NV-U72T
1798	Sony	NV-U73T
1431	Sony	NV-U80
1432	Sony	NV-U81T
1573	Sony	NV-U92
1462	Sony	NV-U92TC
1799	Sony	NV-U93T
1000	Sony	NVX-P1
1660	Sony	NWZ-A816
1847	Sony	NWZ-A829
2174	Sony	NWZ-S639F
1503	Sony	P1i
5	Sony	P910i
1032	Sony	P990i
3961	Sony	Playstation Vita
3155	Sony	PRS-T1
3220	Sony	PS VITA
3221	Sony	PS VITA (Full-Body)
272	Sony	PSP
2039	Sony	PSP 3004
1746	Sony	PSP Slim und Lite
271	Sony	PSP vereinfacht
4523	Sony	PXW-FS7
1858	Sony	R300i
1998	Sony	S302
2528	Sony	S312
1466	Sony	S500i
3094	Sony	SLT-A33
3274	Sony	SLT-A37/58
2723	Sony	SLT-A55V1012
3160	Sony	SLT-A77
3331	Sony	SLT-Alpha 99 / Alpha 99 II
4168	Sony	Smatchwatch 3
1619	Sony	T250i
1839	Sony	T280i
1958	Sony	T303i
1131	Sony	T610
1001	Sony	T630
1585	Sony	T650i
1991	Sony	T700
2320	Sony	T707
2347	Sony	T715
3158	Sony	txt
2966	Sony	txt pro
2333	Sony	U100i Yari
2335	Sony	U1i Satio

2466	Sony	U5i Vivaz
2532	Sony	U8i Vivaz pro
409	Sony	V600i
1204	Sony	V630i
2047	Sony	V640i
2580	Sony	W100i Spiro
2860	Sony	W150i Yendo
1304	Sony	W200i
2310	Sony	W205
1160	Sony	W300i
2022	Sony	W302
1832	Sony	W350i
1817	Sony	W380i
2327	Sony	W395
407	Sony	W550i
1504	Sony	W580i
1990	Sony	W595
1460	Sony	W610i
1480	Sony	W660i
1008	Sony	W700i
2093	Sony	W705
1237	Sony	W710i
2161	Sony	W715
1843	Sony	W760i
37	Sony	W800i
978	Sony	W810i
1163	Sony	W850i
1212	Sony	W880i
1789	Sony	W890i
838	Sony	W900i
1994	Sony	W902
1639	Sony	W910i
1162	Sony	W950i
1650	Sony	W960i
1859	Sony	W980i
2181	Sony	W995
3067	Sony	WT19 Live mit Walkman
4711	Sony	XA2
4707	Sony	XA2 CASEFIT
4712	Sony	XA2 Ultra
4713	Sony	XA2 Ultra CASEFIT
3481	Sony	Xperia Acro S
3038	Sony	Xperia active
2862	Sony	Xperia arc / arc s
3450	Sony	Xperia E
3772	Sony	Xperia E1
3985	Sony	Xperia E1 Dual

3857	Sony	Xperia E3
4052	Sony	Xperia E4
4253	Sony	Xperia E5
3270	Sony	Xperia go ST27i
3289	Sony	Xperia ion LT28h†
3369	Sony	Xperia J ST26i
3475	Sony	Xperia L
3487	Sony	Xperia L, Fullbody Plus
4415	Sony	Xperia L1
3604	Sony	Xperia M
3940	Sony	Xperia M2 FullBody
3822	Sony	Xperia M2/M2 Aqua
4054	Sony	Xperia M4 Aqua
4162	Sony	Xperia M5
2967	Sony	Xperia mini
2968	Sony	Xperia mini pro
3297	Sony	Xperia Miro
2925	Sony	Xperia neo / neo V
3256	Sony	Xperia P LT22i
2874	Sony	Xperia PLAY
3055	Sony	Xperia pro
2970	Sony	Xperia ray
3161	Sony	Xperia S LT26i
3265	Sony	Xperia Sola MT27i
3449	Sony	Xperia SP
3328	Sony	Xperia T
3858	Sony	Xperia T3 (Style)
3348	Sony	Xperia Tipo
3257	Sony	Xperia U ST25i
3368	Sony	Xperia V LT25i
4188	Sony	Xperia X
4262	Sony	Xperia X Compact
4467	Sony	Xperia X Compact - CASEFIT
4190	Sony	Xperia X Performance
4463	Sony	Xperia X Performance - CASEFIT
1907	Sony	Xperia X1
2478	Sony	Xperia X10
2531	Sony	Xperia X10 mini
2572	Sony	Xperia X10 mini pro
2567	Sony	Xperia X2
2607	Sony	Xperia X8
4189	Sony	Xperia XA
4439	Sony	Xperia XA Ultra
4441	Sony	Xperia XA Ultra - CASEFIT
4373	Sony	Xperia XA1
4396	Sony	Xperia XA1 - CASEFIT
4374	Sony	Xperia XA1 Ultra

4397	Sony	Xperia XA1 Ultra - CASEFIT
4254	Sony	Xperia XZ
4465	Sony	Xperia XZ - CASEFIT
4371	Sony	Xperia XZ Premium
4394	Sony	Xperia XZ Premium - CASEFIT
4558	Sony	Xperia XZ1
4559	Sony	Xperia XZ1 - CASEFIT
4561	Sony	Xperia XZ1 compact-†
4562	Sony	Xperia XZ1 compact - CASEFIT
4736	Sony	Xperia XZ2
4737	Sony	Xperia XZ2 - CASEFIT
4739	Sony	Xperia XZ2 Compact
4372	Sony	Xperia XZs
4395	Sony	Xperia XZs - CASEFIT
3528	Sony	Xperia Z-†
3406	Sony	Xperia Z Fullbody Premium
3612	Sony	Xperia Z Ultra 6,44 Zoll
3702	Sony	Xperia Z ultra Fullbody
3648	Sony	Xperia Z1
3747	Sony	Xperia Z1 compact
3748	Sony	Xperia Z1 compact FullBody
3627	Sony	Xperia Z1 Fullbody
3770	Sony	Xperia Z2
3820	Sony	Xperia Z2 Full Body
3882	Sony	Xperia Z3
3883	Sony	Xperia Z3 compact
3894	Sony	Xperia Z3 compact FullBody
3893	Sony	Xperia Z3 FullBody
4085	Sony	Xperia Z3 Plus
4086	Sony	Xperia Z3 Plus FullBody
4093	Sony	Xperia Z5
4095	Sony	Xperia Z5 compact
3476	Sony	Xperia ZL
4740	Sony	XZ2 compact - CASEFIT
1169	Sony	Z300i
1620	Sony	Z320i
835	Sony	Z520i
1502	Sony	Z530i
1159	Sony	Z550i
1183	Sony	Z610i
1238	Sony	Z710i
2577	Sony	Zylo
787	Speedlite	550 EX
788	Speedlite	580 EX
2583	Swissphone	Boss 925
343	T-Com	Sinus WDA
1217	T-Mobile	Ameo

6	T-Mobile	MDA / MDA II
8	T-Mobile	MDA Compact
856	T-Mobile	MDA Compact II
1151	T-Mobile	MDA Compact III
1884	T-Mobile	MDA Compact IV
2188	T-Mobile	MDA Compact V
7	T-Mobile	MDA III
1501	T-Mobile	MDA Mail
401	T-Mobile	MDA Pro
1636	T-Mobile	MDA Touch
1804	T-Mobile	MDA Touch Plus
283	T-Mobile	MDA Vario
1134	T-Mobile	MDA Vario II
1742	T-Mobile	MDA Vario III
2010	T-Mobile	MDA Vario IV
2212	T-Mobile	MDA Vario V
3350	T-Mobile	Move
2370	T-Mobile	Pulse
2861	T-Mobile	Pulse mini
25	T-Mobile	SDA
256	T-Mobile	SDA Mini
26	T-Mobile	SDA Music
30	T-Mobile	Sidekick II
344	Tchibo	Navi TCM 2005
3689	Tecmobile	You 25
284	Telme	T919
1433	Tevion	GPS-Navi
2042	THB	Burry CC9060
1497	Thompson	GPS 280/281
1498	Thompson	GPS 420
1144	Thyphoon	MyGuide 3620 Go
330	Thyphoon	MyGuide 5500
331	Thyphoon	MyGuide 5500 XL
332	Thyphoon	MyGuide 6500
333	Thyphoon	MyGuide 6500 XL
2702	TiBook	NL2
3886	Tolino	Vision
4133	TomTom	Bridge
273	TomTom	GO 300
861	TomTom	GO 500
4104	TomTom	Go 510 (2015)
1010	TomTom	GO 510/710/910 (2008)
1580	TomTom	GO 520T/720T/920T
3654	TomTom	GO 600
1833	TomTom	GO 630T/730T/930T
274	TomTom	GO 700
1934	TomTom	GO 740/750/940/950 LIVE

2229	TomTom	GO LIVE
2792	TomTom	GO Live 1000
2865	TomTom	GO Live 1005
2927	TomTom	GO LIVE 825
999	TomTom	ONE Regional/Europe
1655	TomTom	ONE Version 2
1656	TomTom	ONE Version 3
1434	TomTom	ONE XL
3101	TomTom	Pro 7100 Truck
2900	TomTom	Pro 7150 Truck
998	TomTom	RIDER
4199	TomTom	Rider 40/400
3216	TomTom	Start 25
2891	TomTom	VIA 125 Europe Traffic
4297	TomTom	Vio
2231	TomTom	XL
1844	TomTom	XL Europe/Regional/Traffic
2230	TomTom	XL LIVE
2351	TomTom	XXL IQ Routes
276	Toshiba	E400
277	Toshiba	E740
278	Toshiba	E800 WIFI
3884	Toshiba	Encore WT8 A
3745	Toshiba	Exite Pro
2701	Toshiba	Folio 100
2090	Toshiba	PC e750
2189	Toshiba	TG01
3150	Trekstor	eBook-Reader 3.0
1164	Trekstor	i.Beat joy2.0
2805	Trekstor	SmartPhone
2813	Trekstor	SmartPhone
4128	Trekstor	WinPhone 4.7
4311	uleFone	Future
3286	Utano	Barrier T180
1435	VDO Dayton	MM2100
1436	VDO Dayton	MM5200
1437	VDO Dayton	MM5300
1438	VDO Dayton	MM5500
1440	VDO Dayton	PN2050
1439	VDO Dayton	PN3000
1132	ViaMichelin	X930
1441	ViaMichelin	X950
1442	ViaMichelin	X950T
1574	ViaMichelin	X960
1575	ViaMichelin	X970T
1576	ViaMichelin	X980T
285	Viewsonic	V35

3061	Viewsonic	V350	
2397	Vodafone		541
3016	Vodafone		547
2863	Vodafone		553
3346	Vodafone		555
2546	Vodafone		736
2062	Vodafone		830
2553	Vodafone		845
2921	Vodafone	858 smart	
3988	Vodafone	Smart 4 mini	
3975	Vodafone	Smart 4 Turbo	
3601	Vodafone	Smart III 975N	
4276	Vodafone	Smart Platinum 7	
2054	Vodafone	VDA GPS	
1911	Vodafone	VDA V	
279	Vodafone	VPA	
287	Vodafone	VPA Compact	
1816	Vodafone	VPA Compact GPS	
857	Vodafone	VPA Compact II	
1209	Vodafone	VPA Compact III	
2364	Vodafone	VPA Compact IV	
1030	Vodafone	VPA Compact s	
1675	Vodafone	VPA Compact V	
288	Vodafone	VPA III	
845	Vodafone	VPA IV	
844	Vodafone	VPA Mini	
1676	Vodafone	VPA Touch	
933	Voigtlaender	D 5/6	
932	Voigtlaender	D 8	
2290	Voigtlaender	Vitoret 73	
2324	Voigtlaender	Vitoret U8	
2150	Voigtlaender	XM 1060	
1117	Voigtlaender	XM 7.0	
1116	Voigtlaender	XM 8600	
3825	Wiko	Barry	
3941	Wiko	Birdy	
3868	Wiko	Bloom	
3817	Wiko	Cink Peax 2	
3916	Wiko	Cink Slim 2	
3800	Wiko	Darkmoon	
3885	Wiko	Fizz	
3899	Wiko	Getaway	
4638	Wiko	Harry	
3826	Wiko	Highway	
3994	Wiko	Highway Signs	
3829	Wiko	Iggy	
4310	Wiko	Jerry	

3971	Wiko	Lenny
4129	Wiko	Lenny 2
4328	Wiko	Lenny 3
4163	Wiko	Pulp 3G/4G
4303	Wiko	Pulp FAB 4G†
4096	Wiko	Pure
3821	Wiko	Rainbow
4198	Wiko	Ridge 4G
4480	Wiko	Robby
4005	Wiko	Slide
3900	Wiko	Stairway
4430	Wiko	Tommy
4723	Wiko	U FEEL†
4724	Wiko	U FEEL - CASEFIT
4721	Wiko	U FEEL PRIME
4722	Wiko	U FEEL PRIME - CASEFIT
3974	Wiko	Wax
3361	Wolfgang	AQ 28D
3360	Wolfgang	AS 28 D
3363	Wolfgang	AS 43D
3362	Wolfgang	AS 43D2
3407	Wolfgang	AS40SE
3978	Wolfgang	AS40W
3408	Wolfgang	AS45 SE
3979	Wolfgang	AS50HD
3448	Wolfgang	AS53N
3980	Wolfgang	AS55HD
3977	Wolfgang	AS55HD1
3006	xplore	iX104C5
345	Yakumo	Alpha
282	Yakumo	Delta 300/400
1443	Yakumo	Easy go
1444	Yakumo	Easy go XS
1445	Yakumo	Easy go XSC
4292	ZTE	Axon 7
4631	ZTE	Axon 7 - CASEFIT
4293	ZTE	Axon 7 mini
2806	ZTE	BASE lutea
3089	ZTE	Base Lutea 2
3381	ZTE	Blade / T-Mobile Blade
3739	ZTE	Blade 3
4120	ZTE	Blade A452
4119	ZTE	Blade C341
3714	ZTE	Blade G
4146	ZTE	Blade L3
4701	ZTE	Blade L5†
4332	ZTE	Blade V7

4473	ZTE	Blade V7 - CASEFIT
4331	ZTE	Blade V7 lite
4475	ZTE	Blade V7 lite - CASEFIT
4551	ZTE	Blade V8
4552	ZTE	Blade V8 - CASEFIT
4030	ZTE	Blade Vec 4G
4056	ZTE	E9Q
3712	ZTE	Grand Memo
3583	ZTE	Grand X
3848	ZTE	Kis Plus
3757	ZTE	Open
2817	ZTE	Racer
3170	ZTE	Racer II
2973	ZTE	Skate
3382	ZTE	V871